

INSTALL INSTRUCTIONS



FJ CRUISER REAR BUMPER

300135-KIT

KIT CONTENTS

1 ct.

Heat Shield



2 ct.

Carriage Bolts



2 ct.

Bolt, M12-1.25x40



2 ct.

Bolt, M8x1.25x30



4 ct.

Washer, 1/2" Grade 8



2 ct.

Carriage Bolt Retainers



2 ct.

Flange Nuts



2 ct.

Fender Washers, M8



4 ct.

Washer, 1/2", Fender



2 ct.

Top Lock Nuts



1 ct.

FJ Cruiser Rear Bumper





RECOMMENDED TOOLS

3/8" Ratchet:

Sockets: 1/2", 11/16", 3/4" 13mm

Wrench: 11mm

CAUTION

1. Read all instructions completely and carefully before you begin.
2. Check to make sure the kit is complete and that no parts are missing (refer to the Kit Contents List on the first page of these instructions). If anything is missing, please contact Trail-Gear at 559.252.4950.
3. Park vehicle on a clean, dry, flat, level surface and block the tires so the vehicle can not roll in either direction.

INSTALL INSTRUCTIONS (CONT'D.)



STEP 1

Remove plastic factory frame plugs on both the driver and passenger side of the vehicle



STEP 2

The provided carriage bolt will pass through this hole in the frame.



STEP 3

Install carriage bolt retainer so that the longer side is towards the front of the vehicle. Position the square hole over the hole in previously indicated.



STEP 4

Drop carriage bolt through the carriage bolt retaining plate. A magnetic tool can be used to help with installation.



STEP 5

Repeat steps 3 and 4 on the opposite side of the vehicle.

STEP 6

When installed the carriage bolt should look like this



INSTALL INSTRUCTIONS (CONT'D.)



STEP 7

Install and tighten provided hardware on both sides of the vehicle.



STEP 8

Install heat shield using 1/4" Hardware supplied.

