

INSTALL INSTRUCTIONS



FJ CRUISER FRONT BUMPER

300137-KIT (W/STINGER)

300182-KIT (LOW PROFILE)

KIT CONTENTS

2 ct.

Bolt, M12-1.25x30



2 ct.

Washer, Fender, M12



8 ct.

Washer, Flat, M10



8 ct.

Nut, Nylock, M10-1.25



1 ct.

FJ Cruiser Front Bumper



OR





RECOMMENDED TOOLS

3/8" Ratchet

Sockets: 10mm, 17mm, 3/4"

Screw Drivers: Slot, Philips

CAUTION

1. Read all instructions completely and carefully before you begin.
2. Check to make sure the kit is complete and that no parts are missing (refer to the Kit Contents List on the first page of these instructions). If anything is missing, please contact Trail-Gear at 559.252.4950.
3. Park vehicle on a clean, dry, flat, level surface and block the tires so the vehicle can not roll in either direction.

INSTALL INSTRUCTIONS (CONT'D.)



STEP 1

Remove factory bumper and grill.



STEP 2

Re-route A/C line in order to provide clearance for the bumper. The A/C line will now pass behind the center radiator core support.



STEP 3

Remove upper OEM bumper support bracket. Shown here.



STEP 4

Cut headlight support as shown (optional).



STEP 5

Slide bumper over mounting bolts



STEP 6

Install and tighten provided bolts and washers.



INSTALL INSTRUCTIONS (CONT'D.)



STEP 7

Trim inner fender as shown below.



STEP 8

Front Bumper Installed. Additional upgrades shown.

