



Incorporated  
762 Bonham Avenue / Columbus, Ohio 43211

### JEG'S WHEELIE BARS

# 40007 With housing bracket

# 40008 without housing brackets

(fits Jeg's ladder bars or four link)

#### # 40007 BARS

Assemble the bars as shown in the illustration. Turn the adjuster so that the upper strut length matches the hole spacing from the front housing bracket to the rear wheel bracket without flexing the aluminum bar. Position the assembled bar on the housing with the wheel 4 inches from the ground. Tack weld in place. Check alignment. Finish the welds. The bar may now be adjusted up or down as desired. Hold the wheel vertical while tightening the jam nut.

#### # 40008 BARS

Bolt the aluminum bar to the ladder bar or the four link housing bracket with one bolt. Align the bars. Drill the other hole from the bottom through the aluminum and through the housing bracket. Assemble the remainder of the bar. Adjust the bar as desired. Hold the wheel vertical while tightening the jam nut.

