

JEGSTER UPPER COIL-OVER SHOCK MOUNT KIT 550 40017

- * This shock crossmember is usually positioned between the frame rails.
- * The shocks should be positioned as far apart, rt. to left, as clearance will allow.
- * The shocks should be installed on the car vertical or close to vertical.
- * The spacers are for ball end shocks and may be left out if other type shocks are used.
- * Use this upper shock mount with Jegster 550 40015 adjustable lower mounts or with 550 40019 or 40020 four link kits with adjustable lower mounts included.
- * Most drag race applications should have the shocks positioned close to 3/4 collapsed at ride height (including rubber stop compression).
- * After tack welding the mounts in place, carefully check clearance with other suspension parts. Make sure to check clearance through full shock travel.
- * Finish all the welds and assemble.

