



Information and Installation

762 Bonham Avenue • Columbus, Ohio 43211

Phone: 1-800-345-4545 • FAX (614) 299-4444

550 40053 JEGSTER 1982 - 92 CAMARO/FIREBIRD FRAME CONNECTOR KIT

* Jack up the car and support with stands. Place the stands so that you have access to the front of the rear control arms and the area just inside of the rocker panels. Both connectors will fit next to the inside wall of the stock rocker panels. The illustration below shows the connectors as seen from the top. This top surface will fit against the bottom of the floor pan.

* Starting with the passenger side, remove the front bolt in the rear control arm. Slide the frame connector in place from the rear so that the front end goes over the top of the exhaust pipe. You may have to loosen or partially remove the exhaust system to get the connector in place and to provide clearance to drill holes. Position the hole in the rear connector plate in line with the control arm eye and reinstall this bolt. Do not tighten this bolt yet. Raise the front of the connector up against the floor pan with a jack or a stand.

* Remove the door sill cover and pull back the carpet in the area of the front bracket. Using the bracket as a jig, drill $3/8$ holes through the floor and install the supplied bolts in these holes with flat washers on top of the floor. Drill the frame hole at the rear of the connector through the bracket and install this bolt with a nut inside the stock frame. Tighten all of the bolts. Reassemble the exhaust system and reinstall the carpet and sill cover.

* The drivers side connector is installed in the same manner except that it is easier because there is no exhaust pipe in the way.

parts included:

- (1) left frame connector
- (1) rt. Frame connector
- (10) $3/8$ x 1 bolts with nuts, flat washers, and lock washers

