



Information and Installation

762 Bonham Avenue • Columbus, Ohio 43211

Phone: 1-800-345-4545 • FAX (614) 299-4444

Jegster 1993-Up Camaro/Firebird Bolt-In Frame Connector Kit • 550-40054

- Jack up the car and support it with jack stands. Place the stands so that you have access to the front of the rear control arms and to the area just inside of the rocker panel.
- Starting with the passenger side remove the front bolt in the rear control arm. Support the right side connector in place under the car, and line up the hole in the rear mount plate with the control arm bolt. Reinstall this bolt but Do Not tighten yet. Raise the front of the connector up against the front sub frame with a jack or a jack stand.
- Using the bracket as a jig, drill 3/8" holes through the frame wall and install these bolts. The nuts and lock washers for these bolts must be placed inside the frame through the drain holes in the stock frame. Drill the frame hole at the rear of the connector through the bracket and install this bolt. Tighten all of the bolts.
- Follow the same procedure to install the driver's side connector.