



Information and Installation

762 Bonham Avenue • Columbus, Ohio 43211

Phone: 1-800-345-4545 • FAX (614) 299-4444

Jegster '79-93 Mustang Bolt-In Frame Connectors Kit • 550-40060

- Raise the car and support it on jack stands to provide working room under the car.
- Slide one frame connector up into position with the bracket in the pocket at the front of the rear sub frame. It may be necessary to move brake lines or fuel lines to allow clearance. Support the frame connector with a jack or a stand. Make sure that the front and the rear brackets are fully seated and that the connector has been slid rearward as far as the pocket bracket will allow.
- Drill $\frac{3}{8}$ " holes in the frame through the holes in the connector brackets starting with the front to rear bolt hole in the pocket bracket. Install this bolt and tighten. Drill the remaining holes. Drill from each side of each rail instead of drilling clear through from one side. This will ensure that the holes line up with the pre-drilled bracket holes. Install the remaining bolts and tighten.
- Repeat this procedure with the other connector.
- This kit is NOT for use with convertibles.

Your Kit Includes:

- 1...Frame Connector (left)
- 1...Frame Connector (right)
- 8... $\frac{3}{8}$ " x 3" Bolts
- 4... $\frac{3}{8}$ " x 1" Bolts
- 4...Flat Washers
- 12...Lock Washers
- 12...Nuts