



762 Bonham Avenue • Columbus, Ohio 43211

Information and Installation

Phone: 1-800-345-4545 • FAX (614) 299-4444

JEGSTER 1994-95 MUSTANG BOLT-IN FRAME CONNECTORS 550- 40061

Raise the car and support it on jack stands to provide working room under the car. Slide one frame connector up into position with the rear brackets on both sides of the front of the rear sub frame. It may be necessary to move brake lines or fuel lines to provide clearance. Support the frame connector with a jack or a stand. Make sure that the front and the rear brackets are fully seated. Drill $\frac{3}{8}$ holes in the frame through the holes in the connector brackets starting with the upper rear. It will be necessary to remove the mufflers, temporarily, to drill these holes. Install the upper rear bolt and install the washers and the nut inside the frame by reaching through the access hole. Drill the bottom rear hole through both sides of the frame and through the connector tab on the outside of the frame. Install this bolt, washer, and nut. Drill the front connector holes from each side of each rail instead of drilling clear through from one side. This will ensure that the holes line up with the pre-drilled bracket holes. Install the remaining bolts and tighten.

Repeat this procedure with the other connector.