

### JEGSTER MUSTANG TRACTION MOUNT 40075

These traction mounts move the instant center back approximately 74 inches and down about 4 inches from the stock position. This is a much more favorable position if you are interested in acceleration. This is accomplished by moving the upper rear control arm mount up only 1/2 inch. These mounts are compatible with Jegster 40076 or 40077 upper control arms or the stock units.

Install Jegster traction mounts one side at a time. With the car raised up and properly supported remove the upper rear control arm bolt. Push the rear of the arm up out of the way and remove the stock rubber bushing. Slide the pivot boss of the Jegster mount through the stock cast boss by starting from a tilted position as illustrated below ( position A ). It will be necessary to temporarily remove the brake line mount from the right side of the car and gently pull the line out of the way. Do not remove the line. When the traction mount is correctly seated the lower U clamp part of the mount will be parallel to the stock casting as illustrated below ( final position ). Install the socket head bolt through the outside of the mount and thread into the bar nut placed inside of the stock casting. Install the long bolt through the lower clamp. Tighten these bolts. The long bolt at the bottom of the part should be tightened so that the clamp closes up only about 1/8 inch. Do not over tighten. Reassemble the control arm and the stock bolt and nut. Repeat the process on the other side of the car. Please grease these pivot points regularly.

