



Incorporated
762 Bonham Avenue / Columbus, Ohio 43211

JEGSTER SWITCH PANELS 40320, 40321

40320 Assemble the aluminum backing plate to the end brackets with the screws provided. Weld the end brackets to the cage bar in the desired position. Remove the aluminum plate to paint the brackets with the cage. Assemble the backing plate, the face plate, and the switches and reattach to the brackets after the wiring is done.

40321 Determine the desired location for the switch panel in the dash. Cut a 7 1/4" x 2" rectangular hole for the switches. Assemble the backing plate, the face plate, and the switches. Hold the assembly in place and drill four 3/32" holes in the dash through the existing holes in the face plate. Assemble after the wiring is done with the screws provided.