



Incorporated
762 Bonham Avenue / Columbus, Ohio 43211

JEG'S GLASS DOOR HINGE KIT #40406

The hinge pin axis should be in the same location as the stock hinge pins were. The upper pin should be as high as possible on the front surface of the door and the lower pin should be as low as possible without causing clearance problems. The pin mount tubes should be welded to the front roll cage posts. On some cars it may be necessary to bend these pin mount tubes to clear body panels or other obstacles. The rivet plate should be temporarily installed on the front edge and the lower rear surface of the door while the hinge parts are tack welded together. Check door alignment carefully, remove the hinges, finish welds, and, reinstall. The strut inside the door should be installed last, welded in place from top hinge to lower rear rivet plate.

