

JEGSTER CONTROL ARMS

550 41030 lower control arms

550 41031 upper control arms

These control arms are designed to fit Jegster front frames 550 41025, 550 41026, and 550 41027.

Use Jegster ball joints 550 41033. The ball joints are sold in pairs. These joints are sometimes called screw in type. The Jegster control arms are designed to have the ball joints pressed in place. Apply anti-seize compound to the body of the ball joint and press into the control arms so that the head of the joint is inside the control arm boss. Please do not hammer the ball joints in. The head of the joints should seat flat against boss flange. Use proper fitting press spacers so that the joint goes straight in. Install the aluminum ball joint caps in the upper arms using the bolts included.

The upper arms are interchangeable, right to left. The lower ones are not. Install the lower arms with the ball joint sockets towards the front of the car.

The Jegster ball joints have 3/8" thick spacers included. Use the spacers between the nut and the spindle on the lower ball joints. Discard the spacers with the upper joints.

Install the lower arm mount bar with 4 to 6 shim washers on each mount bolt as a preliminary alignment setting. Follow the instructions included with the front frame carefully.