

JEGSTER TIE ROD ADAPTERS 550 41032

Assemble the tie rod adapters as shown below. There should be about 6 threads showing on the rod end. Install the rack and pinion and turn the steering shaft to centered position. Bolt the adapters to the steering arms and slide the adapter tube over the rod. The rods may need shortened to allow the hubs to be turned straight ahead. Weld the tubes to the rods. Adjust the alignment as described in the front frame instructions.

