

JEGSTER TRACTION BARS 41040 - 41041 - 41042 - 41043 - 41044 - 41048

- 1 Raise the rear of the car and place jack stands under the frame ahead of the springs, NOT UNDER THE HOUSING.
- 2 Disassemble - remove rear wheels, lower shock bolts, lower the jack so that housing is hanging on the springs, remove U bolts and lower spring plate. Take care to avoid damaging brake lines during entire installation.
- 3 Install the bars as shown below in place of the removed spring plates. Install so that the shock mounts match the shock locations. Line up the bars so that the front is centered under the spring. Tighten the U bolts. New U bolts are recommended and are available from JEGS. U bolts are 555 60510, or 555 60511, or 555 60512.
- 4 Jack up the housing so that the front clamps and shims can be assembled. Install 1 shim between the bar and the spring on the drivers side and 2 shims on the passenger side. The entire weight of the car should be on the front tires and the rear housing before the clamp bolts are tightened. Finish reassembling and test drive. Re-check bolt tightness periodically.

