

Installation Instructions for 10220, 10222, and 10223 Battery Boxes

Components:

- 2 Bolts
- 2 Lock Nuts
- Box Assembly
- Aluminum Retaining Strap

Installation and Assembly Instructions (10220 & 10222):

- 1) Weld the battery box onto the frame of the vehicle. Pick a location that will allow enough clearance to fit the battery and battery cables. After welding and part has cooled down, clean and paint the battery box.
- 2) Remove the lock nuts from the bolts, and slide the bolts through the holes in the sides of the battery box from the inside.
- 3) Slide the aluminum retaining strap over the bolts and over the edge of the battery.
- 4) Tighten the lock nuts to retain the battery.

Install part number 10223 in a similar manor except that it is bolted to the frame of the vehicle. You can also mount the 10223 using ballast mount part numbers 64801 through 64812 to mount this battery box on a tube frame race car. It is suggested that you use 3 or 4 of these mounts and locate the battery box where it can be mounted to one vertical and one horizontal chassis tube. This method of attachment allows changes to be made in the location of the battery and this can change the way the car handles or hooks up. Keep in mind that you will need to change the length of the battery cables when moving the battery box.

