

Installation Guide

Upgraded Aluminum Engine Oil Filter Housing with Oil Cooler and Filter

2011-2023 Chrysler, Dodge, Jeep, Ram

555-50348

1. Install and hand start all bolts into oil filter housing.
2. Lightly snug all bolts down evenly.
3. Follow torque sequence displayed in the image.
4. Torque all bolts to 60 **Inch**-Pounds in sequence.
5. Torque all bolts to 106 **Inch**-Pounds in sequence.

WARNING

All torque specs listed in this guide are in **INCH-POUNDS**.

TORQUE SEQUENCE

