

Assembly Guide

Shop Stool

555-81185



Table of Contents

Table of Contents	01
Read Before Assembly	01
Tools Needed	01
Parts List	02
Assembly	03-05

Read Before Assembly

Thank you for your purchase of this JEGS Shop Stool. Before assembly, please be sure to verify that all of the components have been received. Reference the parts list on the previous page. If any components are missing or damaged please contact customer service at: 1.800.345.4545.

If you are having issues, or have questions regarding the assembly of this shop stool, please contact our technical support department at: 1.800.345.4545.

Return Information: Before modifying any of the parts of this shop stool, please trial fit all components. ***Once this stool has been modified, it will not be accepted for return.***

Tools Need

The following tools are needed for the assembly of this shop stool.

- 14mm wrench for all bolts
- 15mm wrench for all nuts
- 5mm hex screwdriver

Parts List



PART #	PART	QTY	PART #	PART	QTY
1	Seat Cushion	1	7	Casters	3
2	Gas Strut	1	8	Locking Casters	1
3	Handle Tray	1	9	Bolts (M10-1.5)	10
4	Fixed Sleeve	1	10	Nuts (M10-1.5)	15
5	Curved Brackets	5	11	Screws (M6-1)	4
6	Angle Brackets	5			

Assembly



Step 1

- Insert the five angled brackets (#6) into the fixed sleeve (#4).
- The fixed sleeve collar needs to be located toward the top.
- Secure the brackets with nuts (#10) and bolts (#9).



Step 2

- Tighten hardware once assembled.



Step 3

- Assembly of the curved brackets (#5), which secure the casters, is made by stacking their end brackets as shown above. The notch on the side of the bracket located around the square casting on the adjoining bracket.

Assembly Cntd.



Step 4

- Place the end of the angled bracket (#6) into the slot where the two curved brackets (#5) join.



Step 6

- Alternate locking (#8), and non-locking (#7), casters as you install them.



Step 5

- The underside of the curved bracket (#5) has a recess to secure the hex nut base of the caster (#7 & #8).
- Push the caster's threaded rod through the brackets and secure with a nut (#10).



Step 7

- At this point the base of the stool is complete. Ensure that all hardware is secure.

Assembly Cntd.



Step 8

- Slide the gas strut (#2) into the fixed sleeve (#4).



Step 10

- Place the tray handle (#3) onto the gas strut (#2) and press down to securely attach.



Step 9

- Secure the handle tray (#3) to the seat cushion (#1) using the supplied screws (#11).



Step 11

- Squeeze the handle to raise, or lower, the seat to the desired height.



If any components of this Shop Stool are missing or damaged,
or if you have any questions contact us at 1.800.345.4545

Return Information: *Once the stool has been
modified, it will not be accepted for return.*

JEGS.com

1-800-345-4545