

Installation Instructions for 81721 Shot Bag Stand

Set-up Instructions:

1. After unpacking all items, pre-assemble top, bottom & post.
2. Check for height fit for main user. The stand post, after setting height, with a filled shot bag should be cut to have the shot bag height at user crouch level. When hammer forming this will help eliminate stress and increase your personal comfort and control of the mallet.
3. We strongly recommend filling the post with Redi-Mix concrete or equivalent for added stability and absorption of impact forces. This can be accomplished by masking of bottom of the tube/post after cutting to height, place in base and fill up post core approx 18" from bottom. **DO NOT FILL TO TOP OF TUBE/POST.**
4. Some shimming of the post OD to the stand/top ID may be necessary. Small strips of sheet metal in the 20-24 gauge will work fine.



**Shot / Sand Bag
Sold Separately**