

Installation Instructions for 93009

Bug Shield Deflector

No Drill

Hardware Included: (4) - #14 X 1/2 Phillips Truss, (4) - BAS Washers, (4) - Flat Bump-ons

- 1) Thoroughly clean front hood area. Open hood.
- 2) "Dry Fit" the bug shield by holding it up to the hood. (This will also help verify if you have the correct shield for your vehicle).
- 3) Remove ONLY the plastic plugs from the weather-stripping that corresponded with the holes in your bug shield (using a pair of pliers or a fork).
- 4) Now, with the screws and washers provided, attach shield by screwing into the pre-existing holes.

DO NOT OVER TIGHTEN SCREW OR YOU WILL VOID THE WARRANTY.

- 5) Before closing the hood make certain the shield is properly centered by "eyeballing" the two ends (you may need to loosen the screws and move the shield to either the left or right).
- 6) To insure the bug shield does not come in contact with the grill, adhere the bump-ons onto the grill, evenly spaced (so the shield rests on the bump-ons)
- 8) Close hood.

Cleaning Instructions: Wash with warm water and a mild soap solution using a soft, clean cloth or sponge. Use of cleaners not approved for acrylic, or use of improper solvents could result in permanent damage which will not be covered by the warranty.

Warning: All items are made of breakage resistant material, but to avoid damage, machine car washes are not advised.



1-800-345-4545 jeps.com