

Installation Instructions for 93012

Bug Shield Deflector

Drill

Hardware Included: (4) - #10 X 1/2 Phillip Truss, (4) - Grommets

- 1) Thoroughly clean front hood area. Open hood.
- 2) "Dry Fit" the bug shield by holding it up to the hood. (This will help verify if you have the correct shield for your vehicle).
- 3) Hold bug shield securely in place and lower hood to determine that the shield is centered. Do so by "eyeballing" either end. Make adjustments as needed.
- 4) Mark the position of the two center holes and remove the bug shield.
- 5) Carefully drill the marked holes with a 1/8" drill bit. **IMPORTANT:** Take care not to drill through or damage the top of hood.
- 6) Replace bug shield and install two center holes using the screws and rubber washers supplied.
- 7) Repeat steps 4-6 for the two outside screws.
- 8) Close hood.

Cleaning Instructions: Wash with warm water and a mild soap solution using a soft, clean cloth or sponge. Use of cleaners not approved for acrylic, or use of improper solvents could result in permanent damage which will not be covered by the warranty.

Warning: All items are made of breakage resistant material, but to avoid damage, machine car washes are not advised.



1-800-345-4545 *jegs.com*