

# ***Installation Instructions for 95100 to 95102, 95110, 95111 & 95120 JEGS ABS Hood Scoops***

## **Overview:**

The JEGS ABS molded plastic hood scoops will be installed on the hood surface with the furnished 3M adhesive tape. These scoops are ready to install and require no trimming or modification. If you are not sure where to position the scoop peruse car magazines, car shows, forums or even the track to see how others have installed theirs so that you can come away with the fitment and look that is most desirable to you.

## **Installation Kits Parts Included:**

(1) ABS Hood Scoop with 3M Automotive Tape Installed

## **Supplies Needed for Installation:**

Bottle of Isopropyl Alcohol

Roll of Masking Tape

***PLEASE READ ENTIRE INSTRUCTIONS BEFORE STARTING YOUR INSTALLATION  
PROPER SURFACE PREPARATION AND DETERMINING LOCATION ARE VERY CRITICAL***

1. Wash your vehicle. **DO NOT WAX. IF NECESSARY REMOVE THE WAX FROM THE INSTALLATION AREA WITH AN APPROPRIATE WAX REMOVAL PRODUCT.** Make sure your vehicle is in a warm area of at least 65 Degrees F for at least one hour prior to installation
2. Mark location on hood exactly where you want the scoop installed.
3. Place the scoop on location you have marked. **DO NOT REMOVE THE ADHESIVE TAPE BACKING AT THIS TIME, THIS STEP COMES LATER.**
4. Using masking tape, outline the perimeter of the scoop
5. Using Isopropyl Alcohol clean the surface of the hood inside the tape edge a minimum of 1/2". **THIS IS CRITICAL AS THE TAPE WILL BOND IN THIS AREA**
6. Remove the backing from the installed tape in the scoop. **TAKE A SECOND LOOK; MAKE SURE THAT THIS LOCATION IS EXACTLY WHERE YOU WANT TO THE SCOOP TO BE INSTALLED. ONCE THE TAPE IS PRESSED ONTO THE HOOD ADHESION WILL BE INSTANT AND THE SCOOP WILL NOT BE ABLE TO BE REMOVED OR RELOCATED**
7. Place the scoop in proper location on the hood. Begin by setting down the back edge first, and then lay the scoop flat. **PRESS FIRMLY ON THE TAPE FOR 30 SECONDS. FIRM PRESSURE ON THE TAPE IS CRITICAL FOR A STRONG BOND**
8. Leave the vehicle in a warm area for at least 1 hour before driving. The tape will be fully cured in 24 hours.



**1-800-345-4545 *jegs.com***