



JET Power-Flo

Throttle Body Spacer Installation Instructions

2005-2007 Nissan Frontier/Pathfinder/Xterra 4.0L

Part #62141

1. Remove throttle body air intake assembly from the throttle body.
2. Remove the (4) four factory bolts from the throttle body.
3. Install the JET Power-Flo throttle body spacer using the supplied o ring.
4. Replace the 4 bolts that mount the throttle body to the intake manifold using the (4) new bolts and (4) flat washers supplied in the kit.
5. Install the two supplied extension plates to relocate the air intake mounting screws.
6. For vehicles that have them verify the throttle linkage, cruise control and kick down cables are NOT binding and that the travel on the linkage is correct before you start the vehicle. NOTE: In some instances it may be necessary to readjust the cables for proper travel, refer to your factory service manual for correct adjustment procedures.
7. Reinstall the Air Intake assembly.

PARTS LIST:

- (1) JET Power-Flo Spacer
- (1) O-Ring Seal
- (2) Extension Plates
- (2) 6mm x 16mm screws
- (4) 6mm x 70mm Bolts
- (4) 6mm Flat Washers

TOOLS NEEDED:

- (1) 10 mm Socket
- (1) Ratchet

JET Performance Products
17491 Apex Cir.
Huntington Beach, CA 92647
Tech: 714-848-5515 FAX: 714-847-6290
www.jetchip.com
customerservice@powerbyjet.com