



JET Power-Flo

Throttle Body Spacer Installation Instructions

2001-up Chrysler PT Cruiser 2.0, 2.4L Non Turbo

Part #62150

1. Remove throttle body cover and air intake assembly from the throttle body.
2. Remove the throttle cables and the bolts that mount the throttle linkage to the throttle body.
3. Remove the bolt and washer from the bracket that supports the throttle body.
4. Remove the 3 bolts that mount the throttle body to the intake manifold.
5. Install the JET Power-Flo spacer using the 3 new bolts and flat washers supplied in the kit.
(NOTE: Reinstall the bolt that mounts the throttle body to the support bracket on the opposite side from the factory installation using the original bolt. Access is easier using a ¼ drive X 12" extension.)
6. Reinstall the throttle cables and bracket.
9. Verify the throttle linkage, cruise control and kick down cables are NOT binding and that the travel on the linkage is correct before you start the vehicle. NOTE: In some instances it may be necessary to readjust the cables for proper travel. Refer to your factory service manual for correct adjustment procedures.
10. Reinstall the Air Intake assembly and cover.

Parts List:

- (1) Powr-Flo Spacer
- (1) O Ring
- (3) 6mm x 55mm Bolts
- (3) 6mm Flat Washers

JET Performance Products
17491 Apex Cir.
Huntington Beach, CA 92647
Tech: 714-848-5515 FAX: 714-847-6290
www.jetchip.com
customerservice@powerbyjet.com