



2010+ CAMARO SS HEADERS AND OEM EXHAUST INSTALLMENT INSTRUCTIONS

DO NOT ATTEMPT this installation if proper safety equipment isn't available to you. Seek the assistance of a professional installer.

- #1—Support vehicle with jack stand.
- #2—Disconnect Positive battery connection located on drivers side fender and in Trunk.
- #4—Remove top motor cover by pulling up.
- #5—Remove spark-plug wires and plugs.
- #6—Remove dipstick .
- #7—Remove (4) O2 sensor from system, let it hang.
- #8—Remove factory exhaust system.
- #9—Remove left and right exhaust manifold.
- #10—Remove Front O2 sensors from clip, and add 8" extension provided. Reconnect O2's to extension and let hang.
- #11—Put a light coat of high temp silicone on head side of gasket than on header, install left and right header. Apply header bolts to headers loosely.
- #12—Install front O2 sensors into headers.
- #13- Now slide left and right Connection pipes into "H-pipe." Loosely start tightening bolts.
- #14—Install left and right O2 extension onto back of connections.
- #15- Tighten Header Bolts to Cylinder Heads and Tighten OEM Clamps to Connection Pipes.
- #16—Reinstall spark plugs and wires.
- #17—Reinstall Top motor cover.

You have just installed the finest exhaust system you can buy, enjoy it.
Thank you for your purchase, we appreciate your business.

**If additional assistance is needed, please contact Kooks Custom Headers
Toll free at 1-866-586-KOOK or contact your dealer.**

Kooks Custom Headers – 141 Advantage Place. Statesville, NC 28677
www.kookscustomheaders.com