



PONTIAC G8 SHORTY HEADER

Do not attempt this installation if proper safety equipment isn't available to you. Seek the assistance of a professional installer.

Kooks G8 headers install from underneath the vehicle. Raising and securing the vehicle with jack stands is a must if a lift is not available.

To install this system you will need a general assortment of hand tools. But you will also want to have on hand the following, four jack stands, one hydraulic jack, a gasket scraper, anti seize, WD-40, surgical gloves, and safety glasses.

It's a good idea to spray the WD-40 to help loosen the connections and fasteners at this time. While the lube is doing its job, we can start the installation

- #1—Support vehicle with jack stand.
- #2—Disconnect negative battery connection located on drivers side fender.
- #3—Remove air box (2) – 10 mm nuts.
- #4—Remove top motor cover by pulling up.
- #5—Remove spark plug wires and plugs.
- #6—Remove dipstick bracket bolt and pull dipstick away from manifold, but **DO NOT REMOVE**.
- #7—Remove O2 sensors from system, let them hang.
- #8—Remove factory exhaust system.
- #9—Mark steering shaft and remove 13 mm bolt from rack and move to the side.

Kooks Custom Headers – 141 Advantage Place, Statesville, NC 28677
www.kookscustomheaders.com



#10—Remove left and right exhaust manifold.

#11—Put a light coat of high temp silicone on head side of gasket than on header, install left and right header. Tighten to factory spec.

#12—Install front O2 sensors into headers. Put a small amount of anti seize on the threads of O2.

#13—Now install exhaust into position with gaskets and hardware provided.

#14—Reinstall spark plugs, wires and 13 mm bolt for the steering shaft.

#15—Install the dipstick bracket spacer between the dipstick bracket and head using provided 10 mm bolt.

#16—Reinstall air box and top motor cover.

**If additional assistance is needed, please contact Kooks Custom Headers
Toll free at 1-866-586-KOOK or contact your dealer**

**Kooks Custom Headers – 141 Advantage Place, Statesville, NC 28677
www.kookscustomheaders.com**