



INSTALLATION INSTRUCTIONS



2015 AUDI TT QUATTRO S MODELS 2.0L TURBO | PART NO. 19089

BILL OF MATERIALS:



WEAR SAFETY
GLASSES



READ INSTRUCTIONS
THOROUGHLY BEFORE
INSTALLING PRODUCT

SHOP SUPPLIES:



SPRAY LUBRICANT

To ease removal of existing exhaust components (especially on older vehicles) spray penetrating lubricant on all fasteners and hangers/insulators that will be loosened or removed and let soak before disassembly.

HARDWARE KIT:

1. [1] 2.50" Clamp

MINIMUM REQUIRED TOOLS:



15mm
13mm
10mm 12 point bit



Hanger Tool
(Or Pry Bar)


MAGNAFLOW RECOMMENDS PROFESSIONAL INSTALLATION ON ALL THEIR PRODUCTS



WARNING: When working on, under, or around any vehicle exercise caution. Please allow the vehicle's exhaust system to cool before removal, as exhaust system temperatures may cause severe burns. If working without a lift always consult vehicle manual for correct lifting specifications. Always wear safety glasses and ensure a safe work area. Serious injury or death could occur if safety measures are not followed.

ATTENTION: Always install any supplied band or U-bolt clamps to the proper torque specifications of 40-45 ft-lbs for band clamps and 30-35 ft-lbs for U-bolt clamps. Over tightening will result in the clamp breaking and will NOT be warranted by MagnaFlow.

INSTALLATION INSTRUCTIONS




Step 1. Begin removal of the OEM system by loosening the clamp at the inlet of the Resonator and removing the passenger side silver structural brace. At the rear of the OEM exhaust you will need to unplug the vacuum line from the exhaust valve. Plug and fasten this line out of the way, it will not be re-used as the new Magnaflow exhaust system does not contain an exhaust valve. You can then disengage the welded hangers from the rubber insulators, working rearward finish removing the system. Do not damage or discard the rubber insulators or OEM clamp as they will be re-used to mount the new system.



Step 2. Begin installation of the new system by attaching the Inlet Pipe Assembly to the factory outlet using the OEM clamp and fit the hangers into the rubber insulators. Leave all clamps loose until final adjustment.



Step 3. Next Install the Muffler Assembly using the supplied 2.50" clamp and fit the welded hanger into the rubber insulator.



Step 4. Once a final position has been chosen for the new exhaust system, evenly tighten all clamps from front to rear using the torque specifications on page one of the instructions. Inspect all fasteners after 25-50 miles of operation and re-tighten if necessary.