

IMPORTANT INSTRUCTIONS

MT1048

Balance Shaft Chain Installation

Install the balance shaft drive chain with the three colored links onto the intake side balance shaft.

Working clockwise around the chain, place the next colored link onto the crankshaft sprocket approximately 6 o'clock position. Place chain on water pump sprocket no timing marks. Align the final link with the timing mark on the exhaust side balance shaft.

Melling Engine Parts

WWW.MELLING.COM

Rev. A