



INSTALLATION INSTRUCTIONS

P/N 22690 - DRY SUMP TANK MOUNTS, OVAL TRACK

Use with Moroso #22660 - Dry Sump Tank or #22662 - Dry Sump Tank or #22664 - Dry Sump Tank

Find a convenient location to mount the holding tank. The mounting brackets should be bolted to 1/8" or thicker steel plates welded to roll bars or any other strong surface. Drill two 3/8" holes 2 1/8" apart for each bracket; leaving approximately 5" in height between the two mounts.

PARTS LIST

2	CLAMPS	2	U-BRACKETS
2	3/8-16 X 4 1/2 BOLT	12	3/8 WASHERS
4	3/8-16 X 1 3/4 BOLT	8	3/8-16 ESNA NUT
2	3/8-16 X 1 1/2 BOLT	1	SPACER, 2.65 LONG
2	3/8-16 X 4" BOLT		

**For Technical Assistance, Call Moroso's Tech Line at
(203) 458-0542, 8:30am – 5:00pm Eastern Time**

MOROSO PERFORMANCE PRODUCTS, INC
80 CARTER DR • GUILFORD, CT 06437-2116
Phone: (203) 453-6571 • Fax: (203) 453-6906