



Installation Instructions

Big Block Chevy Oil Passage Plug No. 23890

PARTS INCLUDED:

- 1 - Oil Passage Plug**
- 2 - 5/16-18 x 1.25 Lg. H. H. C. S.**
- 1 - .125 Round x 3.75 I.D. x 4.00 O.D. O-Ring**

- This kit allows 23840 Oil Filter Block-Off Plate to be used with Gen V Big Block Chevy for Dry Sump Oiling Systems.
- Remove Oil Filter adapter from motor and clean mounting surface and threads completely. Apply Loctite 262 or equivalent to threads of Moroso adapter and install in oil filter adapter location. Torque to 30-35 lb.-ft.
- Use the shorter bolts and round cross section O-ring supplied with this package to install Block Off Plate #23840. Follow installation instructions included in Block-Off Plate package.

***For Technical Assistance, call Moroso's Tech Line at
(203) 453-6571, 8:30am-5:00pm Eastern Time.***

**For Technical Assistance, Call Moroso's Tech Line at
(203) 458-0542, 8:30am – 5:00pm Eastern Time**

MOROSO PERFORMANCE PRODUCTS, INC
80 CARTER DR • GUILFORD, CT 06437-2116
Phone: (203) 453-6571 • Fax: (203) 453-6906