



INSTALLATION INSTRUCTIONS

MOROSO PART NO. 62160 14MM SPARK PLUG INDEXER

Index one set of plugs using your present method. Once you have gotten a set of plugs to index correctly in your cylinder heads, remove one plug at a time and screw into indexer. Scribe the indexer to correspond with the edge of the electrode, and mark with the cylinder number. Do this for all remaining plugs.

From now on, all that is required to index a set of spark plugs is to screw them into the indexer to show into which cylinder they will index properly.

Remember, all cylinder heads are different. A separate spark plug indexer should be used for each set of heads you use.

**For Technical Assistance, Call Moroso's Tech Line at
(203) 458-0542, 458-0546 8:30am – 5:00pm Eastern Time**

MOROSO PERFORMANCE PRODUCTS, INC
80 CARTER DR • GUILFORD, CT 06437-2116
Phone: (203) 453-6571 • Fax: (203) 453-6906