



P/N 63730 – RADIATOR HOSE FILLER 1 1/2 X 1 1/2

P/N 63740 – RADIATOR HOSE FILLER 1 1/2 X 1 1/4

PARTS LIST

- 1 Radiator Hose Filler Assembly

INSTALLATION INSTRUCTIONS

The Radiator Hose Filler is inserted into the top radiator hose close to the inlet from the head or intake manifold.

1. Cut out a 1 1/2" section of the top radiator hose near the water inlet to the hose (at the engine end).
2. Slip two hose clamps over the two pieces of hose.
3. Slide the radiator hose filler into the two hose ends.
4. Turn the radiator hose filler so the filler neck is up.
5. Put clamps in place and tighten.

NOTE: A standard radiator cap will fit onto the radiator hose filler.

***For Technical Assistance, Call Moroso's Tech Line at
(203) 458-0542, 458-0546 8:30am – 5:00pm Eastern Time***

MOROSO PERFORMANCE PRODUCTS, INC
80 CARTER DR • GUILFORD, CT 06437
Phone: (203) 453-6571 • Fax: (203) 453-6906