



BILLET CARBURETOR SPACERS **4150/4160 HOLLEY FLANGE**

PART NUMBERS 64971,64981,64985,64991,64994,65011

PARTS LIST

(1) BILLET ALUMINUM CARB SPACER

(4) 1/8" X 1/2 SPLIT PINS

INSTALLATION INSTRUCTIONS

SPACERS FOR USE ON ALL STANDARD HOLLEY FLANGE, 4 BARREL CARBURETORS.
(CANNOT BE USED WITH 4500 SERIES CARBS).

Center the spacer of the intake manifold plenum area and bolt it in place without the carburetor. Using the 1/8" holes as guides, drill two 1/8" deep locating holes in the intake manifold. Mark the spacer on its outside edge to show mounting position on manifold. Then remove spacer from manifold. Center the spacer on the carburetor and repeat the above procedure, drilling the 1/8" deep locating holes in the carburetor.

Mark the two carburetor gaskets for pin locations and punch two holes for pins in each gasket. Reinstall the spacer to the manifold in the correct position; with a gasket on each side, drive in locating pins, and install the carburetor. Make sure the pins seat completely into the manifold and carburetor.

**For Technical Assistance, Call Moroso's Tech Line at
(203) 458-0542, 8:30am – 5:00pm Eastern Time**

MOROSO PERFORMANCE PRODUCTS, INC
80 CARTER DR • GUILFORD, CT 06437-2116
Phone: (203) 453-6571 • Fax: (203) 453-6906