



U – Joint Girdle 1350 Series Race Yoke

Parts List

- (2) Aluminum Girdles
- (4) 3/8 –24 Counterbore Bolts
- (4) 12 – point Flange Nuts

Installation Instructions

Remove existing u-joint straps.

Push driveshaft towards transmission to gain added clearance for installation of Girdle and Fasteners.

Place 3/8 Bolts through holes in Girdles and secure over u-joint bearing caps with the Flange Nuts.

Tighten bolts evenly making sure that the Girdles come down straight and not cocked to one side. Torque fasteners to 45 ft/lbs.

If needed, grind or file the yoke – DO NOT GRIND THE GIRDLES!

**For Technical Assistance, Call Moroso's Tech Line at
(203) 458-0542, 8:30am – 5:00pm Eastern Time**

MOROSO PERFORMANCE PRODUCTS, INC
80 CARTER DR • GUILFORD, CT 06437-2116
Phone: (203) 453-6571 • Fax: (203) 453-6906