



P/N 94060
POLISHED STAINLESS STEEL AXLE BACK EXHAUST KIT
FORD MUSTANG GT

This product is designed to replace the stock mufflers.

Parts List

1-Driver's side muffler
1-Driver's side pipe
4-Heavy duty clamps

1- Passenger side muffler
1- Passenger side pipe



Installation

- 1) Remove existing muffler at the connection over the rear axle. It will be necessary to remove the hanger brackets also (PAY CLOSE ATTENTION TO THE ORIENTATION OF THE HANGER BRACKETS SINCE THEY CAN BE INSTALLED IN REVERSE AND WILL STILL FIT THE BOLT HOLES IN THE FRAME).
- 2) Clean any rust off the exhaust pipe before attaching the new pipe.
- 3) The exhaust pipe supplied in the kit will attach to the forward-most hanger bracket. Slide the hanger bracket over the exhaust pipe support bar (that is welded to the pipe) before the pipe is attached to the existing exhaust pipe.
- 4) Insert the new pipe over the existing pipe and place the hanger bracket and finger tighten the bolts. Snug the clamp over the new pipe to the existing pipe connection, (DO NOT FULLY TIGHTEN YET).
- 5) Insert the muffler hanger bracket on to the muffler support bar (that is welded to the muffler). Be sure to slide it on in the same orientation that it was removed. Slide a clamp over the muffler inlet and then attach the muffler to the new exhaust pipe outlet. Position the hanger bracket into place and finger tighten the bolts.
- 6) Once the two-piece assembly is in place you can now begin to position the muffler tip centrally in the rear bumper radius cutout.
- 7) The hanger brackets should now be fully tightened.
- 8) Tighten the clamps for each connection while keeping the muffler tip centered in the cutout.
- 9) Repeat this procedure for the other side.

**For Technical Assistance, Call Moroso's Tech Line at
(203) 458-0542, 8:30am – 5:00pm Eastern Time**

MOROSO PERFORMANCE PRODUCTS, INC
80 CARTER DR • GUILFORD, CT 06437-2116
Phone: (203) 453-6571 • Fax: (203) 453-6906