



## INSTALLATION INSTRUCTIONS FOR CHROME HOOD DECK COVER FOR 2005-2007 HUMMER H3 #403506

Congratulations on your purchase of a high quality PUTCO product.  
Should you need any application or technical assistance, feel free to call us at: **1-800-247-3974**  
Monday-Friday 8:00 a.m.- 5:00 p.m. (Central Standard Time)  
Contact your PUTCO dealer for other quality accessories.  
PUTCO Inc. - 216 West First Street - Story City, Iowa 50248



**Please read all instructions before beginning installation and be sure to check to see that all parts and hardware are included.**

**Step 1:** Clean surface of hood vent to remove any dirt, debris, oil, grease and wax. It is recommended to use rubbing alcohol.  
**Note:** The application surface must be warm. Minimum temperature of 10°C (50°F).



**Step 2:** Remove the original part from the vehicle by lifting the front of the part up as shown in the above picture.  
**(Note: Keep the original part.)**



**Step 3:** Determine the part placement by aligning the cover using the front tabs as a guide as shown in the above pictures.



## INSTALLATION INSTRUCTIONS FOR CHROME HOOD DECK COVER FOR 2005-2007 HUMMER H3 #403506

**Step 4:** Remove protective film from part.

**Step 5:** Wipe area second time with a cloth using K-520 Primer Adhesion Promoter or Alcohol to remove all oils and waxes.

**Step 6:** Peel the red backing off the tape located on the back of the hood deck cover.

**Step 7:** Align carefully and press firmly to ensure all tape had come in contact with the cover.

**(NOTE: Once the tape comes in contact with the surface it will adhere immediately and is hard to remove.)**

**Step 8:** Bend rear tabs over on chrome cover to secure to the factory hood deck.



**Step 9:** Insert hood deck with new chrome cover back into place by aligning the clips and firmly pressing it into place.

---

**Note:** PUTCO recommends applying a high quality automotive wax to maintain the original appearance on your new Mirror covers.

---

### LIMITED WARRANTY

Putco guarantees it's Stainless Steel and Aluminum products against defects in workmanship and material for as long as you own your vehicle. Black products have a 90 day warranty on the painted surface. Any defects resulting from faulty material or workmanship will be warranted by Putco and repaired or replaced at our discretion. Putco assumes no extra labor costs. Damages caused by freight carriers, improper installation, misuse, collision, or neglect will not be warranted by Putco.