



A New Generation of Truck Accessories

INSTALLATION INSTRUCTIONS FOR TAILGATE PROTECTORS, ONE PIECE TAILGATE PROTECTORS, & FULL FRONT BED PROTECTORS

Congratulations on your purchase of a high quality PUTCO product. Should you need any application or technical assistance feel free to call us at: **800-247-3974**

Monday - Friday 8:00 a.m. - 5:00 p.m (Central Standard Time)

Contact your PUTCO dealer for other quality accessories.

Putco Automotive Accessories - 216 West First - Story City, Iowa 50248

PLEASE READ ALL INSTRUCTIONS BEFORE BEGINNING INSTALLATION

1. Prior to installation, clean and wax the portion of the truck bed that will be covered.
2. On stainless steel products be sure to remove protective plastic coating before installation.
3. Due to the lateral curvature in some tailgates, it may be necessary to put some downward pressure on each end of the tailgate.
4. Mount with self drill + tapping screws.
NOTE: Attach one end, then the other end, attach middle last.
5. Only the full tailgate protectors and full front protectors come with the double sided tape - apply the tape to the rib parts of the vehicle first, peel off the second side protective tape covering, then mount protector to vehicle. NOTE: Because of the adhesiveness of the tape, you must align the protector correctly the first time. You will not be able to adjust the protector after adhering to vehicle. The use of two people is suggested.

NOTE: if you are going to utilize the double sided tape, do not apply wax to this area.

LIMITED WARRANTY

Putco guarantees its products against defects in workmanship of material for the time period stated. Any defects resulting from faulty material workmanship will be warranted by Putco with the replacement of defective part.

Damages caused by improper installation, misuse, collision, or neglect will not be warranted by Putco. Putco will be sole judge of all warranties! Proof of purchase necessary for all warranty claims.

Aluminum Products	One Year
Stainless Steel Products	One Year
Painted Surfaces	90 Days



¡Una Nueva Generación de Accesorios para Camionetas!

INSTRUCCIONES DE INSTALACION PARA LOS PROTECTORES DE LAS PUERTAS TRASERAS, LOS PROTECTORES DE PUERTAS TRASERAS DE UNA PIEZA Y PARA LOS PROTECTORES DE LAS DELANTERAS DE LAS PLATAFORMAS DE CARGA.

Felicitaciones por su compra de un producto de alta calidad Putco. Si necesitase cualquier asistencia técnica o información sobre su aplicación, por favor llámenos al número de teléfono: **(800-247-3974)** Lunes a viernes de 8:00 de la mañana a 5:00 de la tarde (hora central). Contacte con su concesionario Putco para otros accesorios de calidad.

Putco Inc., 216 West First Street, Story City, Iowa 50248.

POR FAVOR LEA TODAS LAS INSTRUCCIONES ANTES DE COMENZAR LA INSTALACIÓN

1. Antes de comenzar la instalación, limpie y encere la superficie de la
2. En productos inoxidables asegúrese de retirar la cobertura protectora de plástico antes de efectuar la instalación.
3. Debido a la curvatura lateral en algunas puertas traseras, es posible que sea necesario el aplicar cierta presión hacia
4. Móntelo con tornillos de cabeza cruciforme auto perforadores. NOTA: Coloque un extremo, a continuación el otro extremo y por último la parte intermedia.
5. Sólo los protectores para la puerta trasera completa y los protectores para la delantera completa incluyen la cinta adhesiva doble. Aplique primero la cinta adhesiva en las superficies acanaladas del vehículo, despegue el pape protector del otro lado de la cinta y después monte el protector en el vehículo. NOTA: Debido a la adhesividad de la cinta, Ud. debe alinear el protector correctamente la primera vez. Ud. no podrá reajustar el protector después de estar adherido al vehículo. Se requiere la instalación por medios de dos personas.