

PUTCO 2008 FORD SUPER DUTY 900308, 930306 & 920306

REPLACEMENT SIDE MIRROR LENS INSTALLATION SHEET

Congratulations on your purchase of a high quality PUTCO product. Should you need any application or technical assistance feel free to call us at:

1-800-247-3974

Monday-Friday 8:00 a.m. - 5:00 p.m. (Central Standard Time)

Contact your PUTCO dealer for other quality accessories.

PUTCO Inc. - 216 West First Street - Story City, Iowa 50248

Please read all instructions before installation and to check to see that all parts are included.

Section I – Installation Preparation

Kit Contents

Item #	Quantity Reqd.	Description
1	2	Side Mirror Lens

Bolt Kit Contents

Item #	Quantity Reqd.	Description
N/A	N/A	N/A

Recommended Tools

Safety Tools	
Eye Protection	
Special Tools	
Installation Tools	
Flat Head Screw Driver	
Wiping Cloth (non-scratch)	



Legend

	STOP: Damage to the vehicle may occur. Do not proceed until process has been complied with.
	OPERATOR SAFETY: Use caution to avoid risk of injury.
	CRITICAL PROCESS: Proceed with caution to ensure a quality installation. These points will be audited on a completed vehicle installation.
	GENERAL PROCESS: This highlights specific processes to ensure a quality installation. These points will be audited during the accessory installation.
	TOOLS & EQUIPMENT: Calls out the specific tools and equipment recommended for this process.
	REVISION MARK: This mark highlights a change in installation with respect to previous issue.

LIMITED WARRANTY

Putco guarantees it's Stainless Steel and Aluminum products against defects in workmanship and material for as long as you own your vehicle. All painted products have a 90 day warranty on the painted surface. Any defects resulting from faulty material or workmanship will be warranted by Putco and repaired or replaced at our discretion. Putco assumes no extra labor costs. Damages caused by freight carriers, improper installation, misuse, collision, or neglect will not be warranted by Putco. Please consult your Vehicles owners manual for vehicle air flow restrictions. **Putco is not liable for any vehicle damage resulting from the installation of our Grille inserts.**

PUTCO 2008 FORD SUPER DUTY 900308, 930306 & 920306

REPLACEMENT SIDE MIRROR LENS INSTALLATION SHEET

- ➡ 1) Verify Kit Contents.
- ⚠ 2) Remove upper mirror from housing by carefully pulling the mirror back.
(Note: Start from the top and pull outward. Fig. 1)
- ➡ 3) Unclip wire harness from mirror.
- ➡ 4) Remove lens from housing by pressing on the metal tab that is located on the inside of the housing. (Fig. 2)
- ➡ 5) Remove the lights that are plugged into the lens by turning them counter clockwise. (Fig. 3)
- ⚠ 6) Insert the lights into the new replacement lens by turning them clockwise. (Note: Test the light to verify everything is hooked up properly.)
- ➡ 7) Install the replacement lens into the housing by pressing it into place.
- ➡ 8) Plug wire harness into mirror.
- ➡ 9) Install upper mirror by lining the tabs up and pressing into place.
- 🛑 10) Repeat steps 2-9 for the opposite side.



Figure 1



Figure 2



Figure 3

LIMITED WARRANTY

Putco guarantees its Stainless Steel and Aluminum products against defects in workmanship and material for as long as you own your vehicle. All painted products have a 90 day warranty on the painted surface. Any defects resulting from faulty material or workmanship will be warranted by Putco and repaired or replaced at our discretion. Putco assumes no extra labor costs. Damages caused by freight carriers, improper installation, misuse, collision, or neglect will not be warranted by Putco. Please consult your Vehicles owners manual for vehicle air flow restrictions. **Putco is not liable for any vehicle damage resulting from the installation of our Grille inserts.**