



HEADER INSTALLATION INSTRUCTIONS

Corporate Office: PerTronix Inc. 440 E. Arrow Highway, San Dimas, California 91773 * Phone 909.599.5955 * FAX 909.599.6424 * www.patriotexhaust.com

Part #H8073
82-04 Chevy S-10 2WD
Chevy LS Swap
NOTE:

These headers are designed to be used with Car Shop Inc. S-10 Engine Mounting kits



This Product is **ILLEGAL** for Street or Off Highway use and is only intended for Closed Course Competition use, Except for 1965 and older US Manufactured, California Certified vehicles; 1967 and older US Manufactured, Federal Certified vehicles, or 1967 and older Foreign Manufactured vehicles, which may have this product installed as long as the vehicle still meets emissions standards for the year of the vehicle and retains any original or retrofit emissions control devices, including EGR, A.I.R and any NOx device required for the year of the vehicle.

PerTronix® thanks you for choosing **Patriot Headers**, the best value for the dollar of any brand in the industry.
Please read and understand these instructions completely prior to starting work.

Check to make sure you received the proper parts for your application. The header number will be stamped on the engine flange. If you are unsure you have received the proper parts call before you start work.

Be sure to work safe! Whenever you work under the vehicle be sure that it is located on level, solid ground and is supported by adequate safety stands! **Remember: Hot asphalt will not support most jack stands!**

Many factors affect the installation of headers, some of which are broken or aftermarket motor mounts, accidents that impact the configuration of the frame, and/or the installation of different engines or aftermarket cylinder heads.

Attention Customers breaking in new engines: Due to the extreme heat generated during the break-in process, the appearance of the ceramic coating may be altered in certain areas. The protection characteristics and thermal barrier properties of the coating is never compromised. It is recommended that a cast iron manifold or old set of headers be used for this process.

Notice: The coating of these headers can be marred or scratched during installation. If the header needs to be returned and is damaged, you will be charged for recoat.

DISASSEMBLY

1. Disconnect the negative battery cable from the battery.
2. If a car lift is not available, raise the vehicle 2 feet or higher and support with adequate safety stands. Make sure the vehicle is on a flat solid surface and is stable.
3. Remove the spark plugs and wires, oil dip stick tube, and stock manifolds and exhaust.
4. Remove any remaining gasket or carbon deposits from the head surface. The use of a gasket scraper and or a gasket removal product may help.

INSTALLATION

1. Install headers from above using the supplied gaskets and bolts.
2. Reinstall speak plugs and wires and Oil Dip Stick tube.
3. Bolt on the reducers using the supplied gaskets and hardware and weld to your exhaust system.
4. Connect the negative battery cable.

IMPORTANT CHECK LIST

- Be sure that all brake lines and fuel lines are clear of headers and/or connector pipes.
- All spark plug wires, battery cables, or other electrical components should be clear of headers and/or connector pipes.
- If dipstick tube was removed, make sure it is installed properly and that the dipstick has been replaced.
- Double-check the tightness of all bolts including brackets and accessories.

STARTING THE ENGINE

Start the engine and allow it to warm up to operating temperature. Check for any unusual noises or exhaust leaks. If every thing is OK, stop the engine and tighten all bolts while the engine is still warm.

NOTE: Check the bolts periodically to make sure they have not loosened. Re-tighten after the first 500 miles and then again at 1000 miles.

PARTS LIST

Qty	Description
1	Left side header
1	Right side header
2	Header gaskets
12	8mm Header Bolts
6	3/8-16 x1" Collector Hex head bolts
6	3/8-16 Hex Nuts
2	Reducers
2	Collector Gaskets



WARNING:

This product can expose you to chemicals including Lead, Nickel, Cadmium and Chromium which are known to the State of California to cause cancer and birth defects or other reproductive harm. For more information go to www.P65Warnings.ca.gov