

INSTALLATION INSTRUCTIONS

88519-2

Rev C

For Rancho Suspension Strut Tower Kit:

RS886519 — FITS ONLY Ford F-150 4WD equipped with Ranch Suspension RS66519B or RS66500B and OE length front shocks

RS886520 — FITS ONLY Ford F-150 4WD equipped with Ranch Suspension RS66501B and OE length front shocks

READ ALL INSTRUCTIONS THOROUGHLY FROM START TO FINISH BEFORE BEGINNING INSTALLATION



Parts List

P/N	DESCRIPTION	QTY.
RS860746	Sub Assembly, Strut Tower	1
RS770260	Nut, 7/16-20 Nylock	6
RS7726	Washer, 7/16 SAE	6

Included with RS886519

RS176708B	Strut Tower – 4.75”L	2
-----------	----------------------	---

Included with RS886520

RS176750B	Strut Tower – 5.25”L	2
-----------	----------------------	---

- 1) Follow all instructions supplied with applicable Ranch Suspension kit (RS66519B, RS66500B or RS66501B).

Instructions can be obtained by calling the Rancho Technical Department at 1-734-384-7804, or online at <http://www.gorancho.com/install-instructions/>

- 2) Using OE nuts, install strut tower onto OE shock absorber. Tighten to 30 ft. lbs.
- 3) Use hardware from pack RS860746 to attach shock absorber/strut tower assembly to upper mount of vehicle.



www.gorancho.com

Rancho Technical Department 1-734-384-7804.

