



Installation Instructions For Club Car DS Sporting Clay Basket

This Kit Includes:

- | | |
|------------------------------|------------------------|
| (2) Mounting Brackets | (4) M8 Lock Nuts |
| (2) 5/16x1 ½" Hex Head Bolts | (2) 5/16" Flat Washers |
| (4) M8x25 Hex Head Bolts | (8) M8 Flat Washers |
-

1. Remove bolts from bottom of the front strut.
2. Using included 5/16" bolts, install the mounting brackets under the front strut. Then, using included M8 bolts, bolt the sporting clay basket to the mounting brackets.

