



1968-76 Corvette

SHIFTER

- ☐ SW270-C3A GM 3 / 4-spd Auto
- ☐ SW270-C3AR ... Slap-Shift GM 3 / 4-spd Auto
- ☐ SW270-C3A6 ... GM 6 / 8-spd Auto



** SW270-C3A6 will be different than the above image*



www.Shiftworks.com

© 1991 – 2023 Shiftworks™

Installation Instructions

1. Ensure the emergency brake is applied, to keep vehicle from rolling.
2. Remove necessary interior in order to gain access to your factory shifter, be cautious with the wiring.
3. Disconnect the shift cable from the transmission and shifter and remove from car.
4. Remove the factory Shifter from the car.
5. Install the new Shifter.
6. Install the new pan bracket and shift control lever on the transmission.
7. Install the new cable (make sure that the bulkhead that mounts to the shifter is threaded all the way in) The cable is adjusted at the transmission by moving the pin in the shift control lever.
8. Put **BOTH** the transmission and the shifter in OverDrive. The distance from the pin to the face of the pan bracket should be around 5.5"-5.75". Adjust so that the cable eyelet can be freely removed when in gear and so that the shift handle is properly engaged.
9. Run through all the gears to ensure final adjustments.