

PART NO. 23063

2004 GTO MAF

Packing List

Item #	Check	Quantity	Part Number	Description
1.	_____	1	020730500	Sensor, B, MAF, LS1
2.	_____	1	23060A	Adapter. Wire Harness, MAF
3.	_____	1	100064720	Straight Sleeve, MAF Bellow
4.	_____	1	308707426	Clamp, Worm Gear, #056
5.	_____	1	48707483	Clamp, Worm Gear, #064
6.	_____	1	*****	Instructions

Warning: SLP recommends allowing the vehicle to cool (not running) for five hours before beginning the installation. SLP recommends wearing safety glasses for the complete installation.

Installation Instructions

1. Remove the air duct and stock MAF from your GTO.
2. Remove the rubber gasket/seal from the airbox snout that allows your stock MAF to clamp to the airbox lid..
3. This rubber gasket/seal will be a little difficult to remove as there is some glue holding it onto airbox snout.
4. Install the SLP MAF into your stock plastic duct making sure the plastic tab on the MAF is in line with the cutout in the stock duct.
5. The fit will be tight with this new SLP MAF but it will fit with some force and WD-40 on both the duct and MAF.
6. There will be two worm drive clamps provided with this kit. Use the smaller one #056 on the MAF side and the larger one #064 on the airbox side.

7. Plug the adapter into the MAF and then into the GTO's wire harness.
8. See completed installation photo below.

