

Air Filter
1998-02 Camaro/Firebird "Blackwing" High-Flow
C4 Corvette "Blackwing" High-Flow

PACKING LIST

Before installation, use this check list to make sure all necessary parts have been included.

ITEM	QTY	CHECK	PART NUMBER	DESCRIPTION
1.	1	☐	662118	Filter Assy w/Tray
2.		☐	*****	Instructions

INSTALLATION INSTRUCTIONS – #25012B

- 1 This filter comes with a new tray to be used with all 1998-2002 Camaro/Firebird.
- 2 Before installing the tray into your airbox base, snap off the plastic handle on the front side of the tray and trim any excess plastic flush with the front edge.
- 3 This tray will not be used on any C4 corvette using the SLP high flow filter.