

PART #30064

**1997-2004 C5 CORVETTE
X-PIPE/RESONATOR ASSEMBLY**

PART #30065

**1997-2004 C5 CORVETTE
H-PIPE/BALANCE TUBE ASSEMBLY**

PACKING LIST FOR PART #30064

Item #	Check	Quantity	Part #	Description
1	☐	2	300362103	GASKET,OVERAXLE PIPE INLET,C-5 LOUD MOUTH
2	☐	1	310301634	X-PIPE,W/RESONATOR,97-02 C5 VETTE
3	☐	4	30000R	NUT, HEX, 3/8-16 PLATED, GRADE 5
4	☐	4	30010E	BOLT, 3/8" - 16 x 1-1/4" PLATED
5	☐	4	30033B	WASHER, SPLIT LOCK, 3/8 PLATED
6	☐	1	*****	INSTALLATION INSTRUCTIONS

PACKING LIST FOR PART #30065

Item #	Check	Quantity	Part #	Description
1	☐	2	300362103	GASKET,OVERAXLE PIPE INLET,C-5 LOUD MOUTH
2	☐	1	310301633	X-PIPE,W/O RESONATOR,97-02 C5 VETTE
3	☐	4	30000R	NUT, HEX, 3/8-16 PLATED, GRADE 5
4	☐	4	30010E	BOLT, 3/8" - 16 x 1-1/4" PLATED
5	☐	4	30033B	WASHER, SPLIT LOCK, 3/8 PLATED
6	☐	1	*****	INSTALLATION INSTRUCTIONS

INSTALLATION INSTRUCTIONS

NOTE: If using Part #30064 or #30065 to O.E. Midpipe/Converter assembly, SLP Kit #30066 must be used.

INSTALLATION USING O.E. MIDPIPE/CONVERTER ASSEMBLY: From underside of vehicle, locate the two (2) mounting bolts just in front of the catalytic converters that hold the whole assembly to the mounting bracket on the transmission. From the centerline of either bolt head, measure rearward past the converters to 28-1/2", and mark both pipes for cutting. The pipes can be cut in place using a sawz-all, or the whole assembly can be removed from the vehicle and cut on a bandsaw, with

INSTALLATION USING SLP HIGH FLOW CATALYTIC CONVERTERS (PART #30063): (Refer to Figure 14) Follow instructions for installing SLP Part #30063 High Flow Cats. Be sure extension pipes are oriented with correct oxygen sensor "clocking." SLP's H-pipe (Part #30064) and X-pipe with resonator (Part #30065) are designed to simply slip over the outlets of the SLP extension pipes, and are clamped with 3" band clamps. Use the two (2) new outlet gaskets provided when installing.



FIGURE 14