

Part No.**34006-05***10 Shims, .005" Thick***INSTALLATION INSTRUCTIONS**

1. Assemble unit up to and including center support.
2. With dial indicator, check endplay of output shaft.
3. Add .005" shims under 4-tab thrust washer to obtain desired .005" - .025" rear unit endplay.
4. Further adjustments can be done in combination with the OEM spacers listed below.

REAR UNIT ENDPLAY		
OEM Shims	I.D. Notch	No.
.074" – .078"	None	1
.082" – .086"	On the side of 1 tab	2
.090" – .094"	On the side of 2 tabs	3
.098" – .102"	On the end of 1 tab	4
.106" – .110"	On the end of 2 tabs	5
.114" – .118"	On the end of 3 tabs	6