



LIGHTGUARD

FITTING AND INSTALLATION INSTRUCTIONS

- 1) OPEN HOOD.
- 2) CLEAN THE HEADLIGHT LENS.
- 3) POSITION THE DRIVER SIDE HEADLIGHT COVER OVER DRIVER SIDE HEADLIGHT BY PLACING THE BOTTOM TAG OF THE COVER BETWEEN THE LENS AND THE METAL BODY PANEL.
- 4) LIFT THE TOP TAGS SLIGHTLY AND SLIDE THEM OVER THE TOP OF THE HEADLIGHT TRIM.

NOTE: ON SOME VEHICLES IT IS EASIER TO POSITION THE TOP OF THE COVER FIRST AND SLIDE THE BOTTOM IN PLACE.

- 5) REPEAT THE ABOVE PROCEDURE FOR THE PASSENGER SIDE.
- 6) **TO REMOVE:** EASE THE LOWER TAG OF THE HEADLIGHT COVER AWAY FROM THE AUTOMOBILE AND THEN RELEASE THE TOP TAG.

NOTE: THE OPPOSITE WILL APPLY FOR SOME VEHICLES.

HOOD ADJUSTMENT: ON SOME VEHICLES IT MAY BE NECESSARY TO ADJUST THE HOOD STOPS FOR ADEQUATE CLEARANCE. SLOWLY CLOSE THE HOOD TO DETERMINE IF YOU HAVE SUFFICIENT CLEARANCE.

CLEANING INSTRUCTIONS: WASH WITH LOTS OF WARM WATER AND A MILD SOAP SOLUTION USING A SOFT, CLEAN CLOTH OR SPONGE USE OF CLEANERS NOT APPROVED FOR ACRYLIC, OR USE OF IMPROPER SOLVENTS COULD RESULT IN PERMANENT DAMAGE WHICH WILL NOT BE COVERED BY WARRANTY.

WARNING: LIGHTGUARDS ARE MADE OF BREAKAGE RESISTANT MATERIAL, BUT TO AVOID DAMAGE WE RECOMMEND REMOVING THE LIGHTGUARDS PRIOR TO USING AUTOMATIC MACHINE CAR WASHES.