



Corbeau Jeep Cherokee Adapters

Corbeau USA, LLC provides the following mounting bracket installation information as a general set of instructions to help you properly install your Corbeau Seats and Brackets. These instructions are not all-inclusive and may not cover every aspect of installation as some applications may require extra parts or interior modifications. Please contact Corbeau USA, LLC or your local authorized dealer if you have installation questions. We assume no responsibility for proper or improper installation.

Installation Guidelines

1. Remove the original seats and brackets from the vehicle.
2. Remove the stock bracket/sliders from your stock seats.
3. Bolt the Corbeau Jeep Cherokee Adapter to the top of your stock sliders using the OEM hardware.
4. Attach the seat to the top of the Corbeau Jeep Cherokee Adapter using the 4 bolts threaded into the bottom of the Corbeau seat.
5. Re-install the entire assembly into the vehicle using the OEM hardware and ensure all hardware is securely fastened.

Corbeau USA, LLC

Phone: (801) 255-3737

Email: contact@corbeau.com