



VOLANT COOL AIR INTAKES
 PART NO.: 127406
 INSTALLATION INSTRUCTIONS
www.volant.com
 TECH SUPPORT: (909) 481-3888

127406 PARTS LIST						
					2	3/8" LOCK WASHERS
1	VOLANT FILTER BOX	4	#056 CLAMPS		5	1/4" TRUSS HEAD SCREWS
1	VOLANT FILTER BOX LID	3	10/32" X 3/4" BOLTS		5	1/4" RUBBER WASHERS
1	VOLANT AIR DUCT	1	6 MM X 25 BOLTS		1	5/8" STRAIGHT FITTING
1	VOLANT RAM AIR SCOOP	2	8 MM X 20 BOLTS		1	5/8" X 3 1/2" BREATHER HOSE
1	POWERCORE FILTER W/CLAMP	4	1/4" WASHER		1	18 1/4" VINYL TRIM W/SPONGE
1	3 1/4" X 3" SLEEVE	2	3/8" WASHERS		2	SS SELF TAP SCREWS
1	3 1/2" X 3" HUMP HOSE	1	1/4" LOCK WASHER		1	MASS FLOW SENSOR GASKET





Volant Performance
Rancho Cucamonga, CA 91730
(909) 481-3888 Tech Support
(909) 476-1491 Fax
www.volant.com

READ INSTRUCTIONS THOROUGHLY BEFORE DISASSEMBLING. DO NOT SKIP ANY STEPS. ANY QUESTIONS ON A VOLANT KIT MAY BE REFERRED TO OUR TECH SUPPORT LINE AT (909) 481-3888 OR VISIT OUR WEBSITE AT WWW.VOLANT.COM

INSTALLATION INSTRUCTIONS PART NO. 127406

Installation Instructions:

1. Disconnect the negative battery cable.
2. Remove the MAF sensor from the factory duct by removing the two Phillips screws, remove the factory MAF gasket.
3. Remove the two bolts holding the factory engine cover and pull straight up to remove the cover from the engine cover.
4. Remove the two bolts holding the resonator box into place.
5. Using pliers remove the clamp holding the breather hose on the duct pull back to remove the hose.
6. Remove the clamps holding the duct to the throttle body and to the air box then remove the duct from the engine compartment.
7. Remove the rear bolt from the factory air box and remove the box by pulling straight up.
8. Remove the two remaining bolts from the inner fender well.
9. Remove the factory bolt holding the horn bracket to the fender.
10. Attach the horn bracket to the Volant relocation bracket using the hardware provided, reinstall using the factory bolt into factory position moving the horn assembly over 2 inches.
11. Attach the 18.25 trim sponge to the volant air box.
12. Place the box into factory position and tighten the volant box down using the provided hardware.
13. For Xterra models attach the volant cap over the ram air inlet
14. Attach the 3.5 hump hose to the filter box adapter using a #56 clamp.
15. Attach the 3.25 sleeve to the throttle body using a #56 clamp.
16. Attach the Volant duct into the hump hose and sleeve and tighten with 2 #56 clamps.
17. Attach the 5/8 x 3.5 hose to the stem on the volant duct than attach the 5/8 straight fitting into the hose, than the factory hose onto the volant fitting.
18. Slide the MAF gasket onto the Factory sensor and tighten the sensor to the air duct.
19. Reinstall the engine cover and negative battery cable.

WARNING: OVER TIGHTENING HARDWARE MAY ALTAR THE INTEGRITY OF THE VOLANT AIR INTAKE SYSTEM.

BEFORE ROAD TESTING

1. Start engine, leaving the transmission in park and securing the parking brake.
2. Make sure to look and listen for any unusual noises or air leaks. Repair problems if needed.
3. Once completed it will be necessary to check periodically for realignment and tightening of all connections.
4. Once all tests are completed, enjoy the performance of your new Volant Air Intake System.

CARE AND CLEANING

Check the cotton reusable filter periodically and remove any excessive dirt build-up by tapping the filter on the ground and brushing off the loosened dirt. Clean the filter by using Volant's Filter Recharger Kit. Volant's Filter Recharger Kit is designed to restore original air flow. Re-oil every 10,000 miles without cleaning to improve filtering in sand and dirt. Clean only when dirt is very excessive or 50,000 miles.

RECOMMENDED SERVICE PARTS

RECOMMENDED SERVICE PARTS	PART NO.
POWERCORE FILTER REPLACEMENT	61513
COTTON FILTER	5120
PREFILTER	51920

APPLICATION GUIDE

MY	MAKE	MODEL	ENG.
04-07	NISSAN	XTERRA	4.0L

INSTALL

