



2020-2021 C8 Corvette WinMax/ProMax Wiring Harness

PART NUMBER: 12-10119-WFR

PART NUMBER: 12-10119-PFR

INSTALLATION INSTRUCTIONS

This Nitrous Outlet Vehicle Specific Harness is designed specifically for the 2020 and up Chevrolet Corvette with an LT2 engine. If you need any assistance during installation or if you have questions about this wiring harness, call our Tech Help Line at (254) 848-4300.

Tools Needed for Installation*:

- 7mm Socket
- 10mm Socket
- 13mm Socket
- 15mm Socket
- 21mm Socket
- T-15 Torx Bit
- T-30 Torx Bit
- Ratchet
- 12" Extension
- 1" Hole Saw
- 2" Hole Saw
- Drill
- Trim Tool

Additional Materials Needed for Installation:

- Electrical Tape
- Lifting Blocks
- Floor Jack
- Jack Puck
- Wiring Materials

***These are the tools required for installation of this kit on a stock vehicle. If your vehicle has aftermarket parts, other tools may be required.**



Step 1 – Disconnect the Battery

- Open the front storage compartment.



- Remove the trim panels on each side of the vehicle by pulling them from the clips securing them to the body.



- Remove the cowl panel covering the battery by pulling it from the clips securing it to the body.



- Using 10mm socket, loosen the nut and remove the negative battery terminal.

IMPORTANT: All appropriate safety equipment (gloves, tools etc.) must be used during the installation of this product(s).

Nitro Dave's LLC accepts NO responsibility for injuries or damages resulting during and/or from the installation of any product(s). Nitrous oxide is for off-road use only.

WWW.NITROUSOUTLET.COM/INSTALLATION-GUIDES



2020-2021 C8 Corvette WinMax/ProMax Wiring Harness

PART NUMBER: 12-10119-WFR

PART NUMBER: 12-10119-PFR

INSTALLATION INSTRUCTIONS



- Remove the cover over the positive terminal and remove the nut from the terminal with a 10mm deep socket.



Step 2 – Vehicle Disassembly

FRONT STORAGE COMPARTMENT

- Remove the front trim panel from the front storage area by pulling it from the clips securing it to the body.



- Using a T-30 Torx bit, remove the 4 screws from the front storage bin.



- Unscrew the 2 rear tabs holding the storage net.



- Unplug the front storage light/power port connector.

IMPORTANT: All appropriate safety equipment (gloves, tools etc.) must be used during the installation of this product(s).

Nitro Dave's LLC accepts NO responsibility for injuries or damages resulting during and/or from the installation of any product(s). Nitrous oxide is for off-road use only.

WWW.NITROUSOUTLET.COM/INSTALLATION-GUIDES



2020-2021 C8 Corvette WinMax/ProMax Wiring Harness


PART NUMBER: 12-10119-WFR

PART NUMBER: 12-10119-PFR

INSTALLATION INSTRUCTIONS



- Remove the front storage bin from the vehicle.



- Using a 13mm socket and 12" extension, remove the bolt under the brake fluid reservoir.



INTERIOR

- Open the driver door.



- Remove the side trim panel from the center console by pulling it away from the console.



- Pull back the carpet on the console between the seat and the accelerator.

IMPORTANT: All appropriate safety equipment (gloves, tools etc.) must be used during the installation of this product(s).

Nitro Dave's LLC accepts NO responsibility for injuries or damages resulting during and/or from the installation of any product(s). Nitrous oxide is for off-road use only.

WWW.NITROUSOUTLET.COM/INSTALLATION-GUIDES



2020-2021 C8 Corvette WinMax/ProMax Wiring Harness

PART NUMBER: 12-10119-WFR

PART NUMBER: 12-10119-PFR

INSTALLATION INSTRUCTIONS



- Remove the aluminum tape covering the hole in the center console.



- Remove the speaker cover at the top of the console between the seats by lifting it up. It will release from the clips securing it to the body.



- Pull the rear console cover forward and it will release from the clips securing it to the body. You must unplug the speaker and phone charger connectors before removing the cover from the vehicle.



- Pull back the carpet covering the interior fuse box.



IMPORTANT: All appropriate safety equipment (gloves, tools etc.) must be used during the installation of this product(s).

Nitro Dave's LLC accepts NO responsibility for injuries or damages resulting during and/or from the installation of any product(s). Nitrous oxide is for off-road use only.

WWW.NITROUSOUTLET.COM/INSTALLATION-GUIDES



2020-2021 C8 Corvette WinMax/ProMax Wiring Harness

PART NUMBER: 12-10119-WFR

PART NUMBER: 12-10119-PFR

INSTALLATION INSTRUCTIONS



- Remove the cover of the interior fuse box.



ENGINE BAY

- Open the engine compartment.



CHASSIS TUNNEL

- You will need to lift the vehicle off the ground to remove the under-car panels. It is recommended to use an automotive lift. For the do-it-yourself install, use a floor jack with a jack puck and place lifting blocks under all 4 tires.



- Locate the center panel that runs the length of the car. At the rear of that panel is a smaller metal panel with 6 bolts. Using a 15mm socket, remove the 4 rear bolts on that panel. Using a 21mm socket, loosen the 2 largest bolts. The panel should slide rearward and drop off the vehicle.



- At the front of the center panel is another small metal panel. Using a 15mm socket, loosen the bolts holding this panel.

IMPORTANT: All appropriate safety equipment (gloves, tools etc.) must be used during the installation of this product(s).

Nitro Dave's LLC accepts NO responsibility for injuries or damages resulting during and/or from the installation of any product(s). Nitrous oxide is for off-road use only.

WWW.NITROUSOUTLET.COM/INSTALLATION-GUIDES



2020-2021 C8 Corvette WinMax/ProMax Wiring Harness

PART NUMBER: 12-10119-WFR

PART NUMBER: 12-10119-PFR


INSTALLATION INSTRUCTIONS



- Using a 13mm socket, remove the bolts from the center panel and remove the panel from the vehicle.



- Using 10mm, 13mm, and 15mm sockets, remove the rear panel from the vehicle.



- Using 7mm socket and T-15 Torx, remove the front panel from the vehicle.



Step 3 – Harness Installation

- Place the harness assembly on the ground beside the car. The bottle accessory and fuse panel wiring will run to the front of the vehicle.

ProMax electronics bracket shown.



- In the chassis tunnel, use a 10mm socket and extension to remove the 4 bolts holding the HVAC tubing clamps bolts. You will need these bolts to install the electronics panel.

IMPORTANT: All appropriate safety equipment (gloves, tools etc.) must be used during the installation of this product(s).

Nitro Dave's LLC accepts NO responsibility for injuries or damages resulting during and/or from the installation of any product(s). Nitrous oxide is for off-road use only.

WWW.NITROUSOUTLET.COM/INSTALLATION-GUIDES



2020-2021 C8 Corvette WinMax/ProMax Wiring Harness


PART NUMBER: 12-10119-WFR

PART NUMBER: 12-10119-PFR

INSTALLATION INSTRUCTIONS



- Starting at the center of the tunnel under the car, route the switch panel, controller/display, and 12V Switched wiring through the hole in the driver side of the chassis tunnel.



- Using the HVAC clamp OEM hardware (2 steps above), 10mm socket and extension, install the electronics bracket in the chassis tunnel with the controller and relay bracket on the passenger side of the car.




- Route the bottle opener, heater, sensor wiring, fuse panel wiring, and battery connection toward the front of the car beside the HVAC piping.

ProMax electronics bracket shown.



- Pull the harness to the driver side of the car and over the HVAC tubing into the area of the front storage compartment.



- Route the ECU, dedicated tank, and solenoid wiring to the rear of the car past the ECU and up the firewall.

ProMax electronics bracket shown.

IMPORTANT: All appropriate safety equipment (gloves, tools etc.) must be used during the installation of this product(s).

Nitro Dave's LLC accepts NO responsibility for injuries or damages resulting during and/or from the installation of any product(s). Nitrous oxide is for off-road use only.

WWW.NITROUSOUTLET.COM/INSTALLATION-GUIDES



2020-2021 C8 Corvette WinMax/ProMax Wiring Harness

PART NUMBER: 12-10119-WFR

PART NUMBER: 12-10119-PFR

INSTALLATION INSTRUCTIONS



- Use the installation guide in the back of these instructions to put the connectors on your solenoids. After the connectors are installed, plug them into the leads of the wiring harness. There will be separate leads labeled 'Nitrous', 'Fuel', and 'Purge'.



- Route the wires for the dedicated fuel system up the firewall, through the rear passenger wheelwell, and to the dedicated fuel tank. Use the installation guide in the back of these instructions to put the connector on your fuel pump wires. After the connector is installed, plug them into the connector on the wiring harness.



- On the driver side of the center console compartment, an access hole needs to be placed as far forward and as high as possible. Before drilling, remove the switch panel as not to damage it or any switches. Using a 1" hole saw, drill the access hole.

IMPORTANT: All appropriate safety equipment (gloves, tools etc.) must be used during the installation of this product(s).

Nitro Dave's LLC accepts NO responsibility for injuries or damages resulting during and/or from the installation of any product(s). Nitrous oxide is for off-road use only.

WWW.NITROUSOUTLET.COM/INSTALLATION-GUIDES



2020-2021 C8 Corvette WinMax/ProMax Wiring Harness

PART NUMBER: 12-10119-WFR

PART NUMBER: 12-10119-PFR

INSTALLATION INSTRUCTIONS



- Route the wires for the switch panel along the driver side of the center console, then through the 1" hole and to the back side of the panel, connect them per the harness diagram.



- Without pulling the wires from the switches, pull the wiring through the hole in the side of the console until the switch panel is completely on the bottom of the console. Make sure that the console lid does not activate any of the buttons.



- Route the **ProMax** Controller Display Screen or **WinMax** Controller cable along the console. Using a 1" hole saw, drill an access hole.



ProMax only:

- Route the cables for the ProMax Controller Display Screen along the driver side of the center console, then through the 1" hole and plug it in to the display.



WinMax only:

- Route the WinMax Controller wiring along the driver side of the center console and to the 1" hole. Pull the wiring from the WinMax controller from the inside of the center console, through the 1" hole. Using the provided 22-18GA Brazed Butt Connectors and heat shrink, connect the controller leads to the wiring harness with the diagram below.

IMPORTANT: All appropriate safety equipment (gloves, tools etc.) must be used during the installation of this product(s).

Nitro Dave's LLC accepts NO responsibility for injuries or damages resulting during and/or from the installation of any product(s). Nitrous oxide is for off-road use only.

WWW.NITROUSOUTLET.COM/INSTALLATION-GUIDES



2020-2021 C8 Corvette WinMax/ProMax Wiring Harness

PART NUMBER: 12-10119-WFR

PART NUMBER: 12-10119-PFR

INSTALLATION INSTRUCTIONS


WINMAX CONTROLLER

FROM CONTROLLER ----- CAR HARNESS


RED WIRE 18GA	12 V ARM SWITCH	16GA ORANGE
BLACK WIRE 18GA	BATTERY GROUND	16GA BLACK
GREY WIRE 18GA	TACH SIGNAL	16GA PURPLE/WHITE
WHITE WIRE 18GA	TPS SIGNAL	16GA GREEN/WHITE
BLUE WIRE 18GA	STAGE 1	16GA GREEN/ORANGE
GREEN WIRE 18GA	TIMING 1 OUTPUT	16 GA WHITE/BLACK
ORANGE WIRE 18GA	STAGE 2	16GA YELLOW/BLUE
YELLOW WIRE 18GA	TIMING 2 OUTPUT	16GA BLUE/RED




- Route the 12v Source wire along the center console, under the carpet, up to the fuse panel.



- Remove the 15a fuse in position #2.



- Using a wire crimper, connect the provided fuse tap to the labeled harness wire.



- Insert the OEM 15a fuse into the fuse tap.

IMPORTANT: All appropriate safety equipment (gloves, tools etc.) must be used during the installation of this product(s).

Nitro Dave's LLC accepts NO responsibility for injuries or damages resulting during and/or from the installation of any product(s). Nitrous oxide is for off-road use only.

WWW.NITROUSOUTLET.COM/INSTALLATION-GUIDES



2020-2021 C8 Corvette WinMax/ProMax Wiring Harness

PART NUMBER: 12-10119-WFR


PART NUMBER: 12-10119-PFR

INSTALLATION INSTRUCTIONS



- Insert the fuse tap into position #2 on the fuse panel.

C8 Corvette Fuse Panel Diagram on Bulkhead Between Seats



- Just behind the front storage compartment, install the Fuse Panel Mounting Bracket with the OEM bolt and 13mm socket making sure to place the provided spacer between the bracket and the vehicle.

ProMax fuse panel shown.



- Connect the fuse panel wiring per the diagram provided.

ProMax fuse panel shown.

IMPORTANT: All appropriate safety equipment (gloves, tools etc.) must be used during the installation of this product(s).

Nitro Dave's LLC accepts NO responsibility for injuries or damages resulting during and/or from the installation of any product(s). Nitrous oxide is for off-road use only.

WWW.NITROUSOUTLET.COM/INSTALLATION-GUIDES



2020-2021 C8 Corvette WinMax/ProMax Wiring Harness

PART NUMBER: 12-10119-WFR

PART NUMBER: 12-10119-PFR

INSTALLATION INSTRUCTIONS



- Using a 2" hole saw, drill a hole on the back of the front storage compartment, centered just above the sensor.



- Replace the front storage compartment in the front of the vehicle while directing the bottle accessory wiring through the 2" hole from the previous step.



- Plug in the bottle openers and heaters.



For ProMax:

- Plug in the fuel pressure sensor.

For WinMax:

- Remove the jumper wire on the terminal ends of the fuel pressure safety switch wires then plug in the fuel pressure safety switch.

****Note:** If you are not using a fuel pressure safety switch, leave the jumper wire connecting the terminals for the switch.



- If using a timing retard controller, connect the retard output to the controller.

IMPORTANT: All appropriate safety equipment (gloves, tools etc.) must be used during the installation of this product(s).

Nitro Dave's LLC accepts NO responsibility for injuries or damages resulting during and/or from the installation of any product(s). Nitrous oxide is for off-road use only.

WWW.NITROUSOUTLET.COM/INSTALLATION-GUIDES



2020-2021 C8 Corvette WinMax/ProMax Wiring Harness


PART NUMBER: 12-10119-WFR

PART NUMBER: 12-10119-PFR

INSTALLATION INSTRUCTIONS



- In the chassis tunnel, unplug the E4 connector on the ECU. This is the rear most connector.




ProMax only:

- Pin into ECM per pinout diagram.

Tachometer –	J4 connector –	Pin 29 at ECM
TPS –	J1 connector –	Pin 39 at ECM
MAP –	J4 connector –	Pin 58 at ECM
Wideband –	Requires aftermarket wideband controller	

- Steps to use when working with ECM and Sensor connection points.

1. Locate the proper wire.
2. Isolate wires from harness
3. Cut wires
4. Slide heat shrink over wire
5. Solder wires.
6. Slide heat shrink down and melt



WinMax only:

- Pin into ECM per pinout diagram.

Tachometer –	J4 connector –	Pin 29 at ECM
TPS –	J1 connector –	Pin 39 at ECM

- Steps to use when working with ECM and Sensor connection points.

1. Locate the proper wire.
2. Isolate wires from harness
3. Cut wires
4. Slide heat shrink over wire
5. Solder wires.
6. Slide heat shrink down and melt



- Using a 10mm socket, connect the wire between the fuse panel and the positive battery cable.



- Using a 10mm socket, connect the ground wire to the negative battery cable.

IMPORTANT: All appropriate safety equipment (gloves, tools etc.) must be used during the installation of this product(s).

Nitro Dave's LLC accepts NO responsibility for injuries or damages resulting during and/or from the installation of any product(s). Nitrous oxide is for off-road use only.

WWW.NITROUSOUTLET.COM/INSTALLATION-GUIDES



2020-2021 C8 Corvette WinMax/ProMax Wiring Harness

PART NUMBER: 12-10119-WFR

PART NUMBER: 12-10119-PFR

INSTALLATION INSTRUCTIONS



Step 4 – Final Check Over

- Reconnect the battery.




- Verify that tachometer, TPS and MAP function properly.



Step 5 – Final Assembly

- Under the car, reinstall the front panel.



- Under the car, reinstall the rear panel.

IMPORTANT: All appropriate safety equipment (gloves, tools etc.) must be used during the installation of this product(s).

Nitro Dave's LLC accepts NO responsibility for injuries or damages resulting during and/or from the installation of any product(s). Nitrous oxide is for off-road use only.

WWW.NITROUSOUTLET.COM/INSTALLATION-GUIDES



2020-2021 C8 Corvette WinMax/ProMax Wiring Harness

PART NUMBER: 12-10119-WFR

PART NUMBER: 12-10119-PFR

INSTALLATION INSTRUCTIONS



- Under the car, reinstall the center panel.



- Under the car, reinstall both small metal panels.



- In the front storage compartment, reinstall the 2 net tabs.



- Reinstall the 4 mounting screws.



- Reconnect the front storage light/power port connector.

IMPORTANT: All appropriate safety equipment (gloves, tools etc.) must be used during the installation of this product(s).

Nitro Dave's LLC accepts NO responsibility for injuries or damages resulting during and/or from the installation of any product(s). Nitrous oxide is for off-road use only.

WWW.NITROUSOUTLET.COM/INSTALLATION-GUIDES



2020-2021 C8 Corvette WinMax/ProMax Wiring Harness

PART NUMBER: 12-10119-WFR

PART NUMBER: 12-10119-PFR

INSTALLATION INSTRUCTIONS



- Reinstall the 4 trim panels around the front storage compartment.



- Inside the vehicle, reinstall the fuse panel cover.



- Place the carpet over the fuse panel.



- Reinstall the rear console cover. Plug in the phone charger and speaker.



- Reinstall the speaker cover.

IMPORTANT: All appropriate safety equipment (gloves, tools etc.) must be used during the installation of this product(s).

Nitro Dave's LLC accepts NO responsibility for injuries or damages resulting during and/or from the installation of any product(s). Nitrous oxide is for off-road use only.

WWW.NITROUSOUTLET.COM/INSTALLATION-GUIDES



2020-2021 C8 Corvette WinMax/ProMax Wiring Harness

PART NUMBER: 12-10119-WFR

PART NUMBER: 12-10119-PFR

INSTALLATION INSTRUCTIONS



- Push the carpet back in place on the side of the center console then reinstall the side console panel.

IMPORTANT: All appropriate safety equipment (gloves, tools etc.) must be used during the installation of this product(s).

Nitro Dave's LLC accepts NO responsibility for injuries or damages resulting during and/or from the installation of any product(s). Nitrous oxide is for off-road use only.

WWW.NITROUSOUTLET.COM/INSTALLATION-GUIDES




Deutsch Connector Assembly Instructions

INSTALLATION INSTRUCTIONS


Deutsch Connector Assembly:

To assemble Deutsch terminal ends you can use a special crimper, or if done cautiously, this can be done with a pair of needle nose pliers.



Step 1:

Strip the end of the wire you want to place the connector on about 3/8".



Step 2:

Using a crimp tool or needle nose pliers, crimp the connector down. First the smaller crimp and then the larger crimp, make sure the weather pack seal gets crimped with the larger side.



Step 3:

Once your sure you have a good crimp slide the pins into the connector housing being sure to match the wires correctly on each side. Push the pin in the housing until you feel a positive click and the wire cannot be pulled back out of the connector.



Step 4:

Install the provided pin retainer lock in the connector body. It simply snaps in to place.


IMPORTANT: All appropriate safety equipment (gloves, tools etc.) must be used during the installation of this product(s).

Nitro Dave's LLC accepts NO responsibility for injuries or damages resulting during and/or from the installation of any product(s). Nitrous oxide is for off-road use only.

WWW.NITROUSOUTLET.COM/INSTALLATION-GUIDES



WINMAX



WIRING HARNESS

12-10119-WFR – Nitrous Outlet 20-21 GM C8 LT2 Corvette Pro Wiring Harness – WinMax / Front Battery / Rear Dedicated

The WinMax Pro Wiring Harness is designed to be used in conjunction with the Nitrous Outlet WinMax Nitrous Controller in a single or dual stage application.


Standard harness features include, dual timing retard outputs,trans brake interrupt,RPM and TPS inputs, pressure controlled bottle heater, purge, fuel pressure safety switch, remote bottle opener,dedicated fuel system as well as pre-terminated switch panel wiring and pre-terminated Duetsch connectors with an optional high amp inline fuse supply for Direct Port applications.

Applications using dual nitrous bottles will require a Dual Bottle Upgrade which includes an additional bottle heater and remote opener. This upgrade is only available at the time of purchase.

Table of Contents


Single and Dual Stage Wiring Diagram	2-4
Wiring Color and Gauge Identification Chart	5
DualBottle Upgrade Wiring and Components	6
WinMax Pro Harness Connector Identification	7
Direct Port Addendum Connector and Connection	8
12V Switched Fuse and ECM Pin Identification	9
WinMax Pro Harness Overview Body Illustration	10
Pin Out Wiring Color/Gauge Location Chart	11

IMPORTANT NOTICE: You must remove the Stage 1 and Stage 2 wires from the fuse block and reattach them to the provided connector for Multiple solenoid applications such as Direct Port as illustrated on page 10.




IMPORTANT All appropriate safety equipment (gloves, tools etc.) must be used during the installation of this product(s). Nitro Dave's LLC accepts NO responsibility for injuries resulting in the installation of any product(s). Nitrous oxide is for off-road use only.

12-10119-WFR WinMax Wiring Harness - Relay Center C8



IMPORTANT All appropriate safety equipment (gloves, tools etc.) must be used during the installation of this product(s). Nitro Dave's LLC accepts NO responsibility for injuries resulting in the installation of any product(s). Nitrous oxide is for off-road use only.



IMPORTANT All appropriate safety equipment (gloves, tools etc.) must be used during the installation of this product(s). Nitro Dave's LLC accepts NO responsibility for injuries resulting in the installation of any product(s). Nitrous oxide is for off-road use only.

12-10119-WFR WinMax Wiring Harness

Wire Identification and Gauge

FUSE PANEL

STAGE 1 RED 10GA	FUSE 1
STAGE 2 RED 10GA	FUSE 2
BTL OPENER RED 10GA	FUSE 3
PURGE PWR RED 10GA	FUSE 4
DEDICATED PWR RED 10GA	FUSE 5
BTL OPENER RED 10GA	FUSE 6

GREEN 10GA STAGE 1	
YELLOW 10GA STAGE 2	
PINK 10GA BOTTLE HEATER	
BLACK 10GA BATT. GROUND	


WINMAX CONTROLLER

FROM CONTROLLER	CAR HARNESS
RED WIRE 18GA	12V ARM SWITCH
BLACK WIRE 18GA	BATTERY GROUND
GREY WIRE 18GA	TACH SIGNAL
WHITE WIRE 18GA	TPS SIGNAL
BLUE WIRE 18GA	STAGE 1
GREEN WIRE 18GA	STAGE 2
ORANGE WIRE 18GA	TIMING 1 OUTPUT
YELLOW WIRE 18GA	TIMING 2 OUTPUT

12GA BLUE PURGE SOL	16GA RED/WHT 12V SWITCHED
12GA PURPLE BTL OPENER	16GA ARM SW AND DEDICATED PWR
12GA BROWN/WHITE BTL OPENER	16GA BLACK GROUND
12GA PURPLE/ORANGE DEDICATED	12GA BLACK GROUND

SWITCH PANEL CONNECTION GUIDE


Nitrous Outlet 2020 GM C8 LTZ Corvette Pro Wiring Harness –
Frontax / Front Battery / Rear Dedicated



IMPORTANT All appropriate safety equipment (gloves, tools etc.) must be used during the installation of this product(s). Nitro Dave's LLC accepts NO responsibility for injuries resulting in the installation of any product(s). Nitrous oxide is for off-road use only.

12-10119-WFR WinMax Wiring Harness


WinMax Dual Bottle Upgrade Diagram



IMPORTANT All appropriate safety equipment (gloves, tools etc.) must be used during the installation of this product(s). Nitro Dave's LLC accepts NO responsibility for injuries resulting in the installation of any product(s). Nitrous oxide is for off-road use only.


12-10119-WFR WinMax Wiring Harness

WinMax Harness Connections



IMPORTANT All appropriate safety equipment (gloves, tools etc.) must be used during the installation of this product(s). Nitro Dave's LLC accepts NO responsibility for injuries resulting in the installation of any product(s). Nitrous oxide is for off-road use only.

DIRECT PORT ADDENDUM



The Illustration shows the required modification needed to upgrade your WinMax Pro Wiring Harness to a 4 solenoid system such as Direct Port.
(PER STAGE)

IMPORTANT All appropriate safety equipment (gloves, tools etc.) must be used during the installation of this product(s). Nitro Dave's LLC accepts NO responsibility for injuries resulting in the installation of any product(s). Nitrous oxide is for off-road use only.

VEHICLE 12V SWITCHED AND SENSOR CONNECTIONS

CONFIGURATION TYPE: 2020 GM C8 LT2 CORVETTE - Nitrous Outlet 2020 GM C8 LT2 Corvette Pro Wiring Harness — WinMax / Front Battery / Rear Dedicated / Dual Heater / Dual Opener

Fig.1 12V Switched - Fuse 2 located at fuse panel, under console between driver and passenger seat.

Fig.2 TPS - Connector J1 pin 39 at ECM

Fig.3 TACH Connector J4 pin 29 at ECM

MAIN FUSE PANEL BEHIND CENTER CONSOLE



FUSE 2 - 12V SWITCHED

Fig. 1




Fig. 2







Fig. 3

IMPORTANT All appropriate safety equipment (gloves, tools etc.) must be used during the installation of this product(s). Nitro Dave's LLC accepts NO responsibility for injuries resulting in the installation of any product(s). Nitrous oxide is for off-road use only.



SINGLE BOTTLE SYSTEM



DUAL BOTTLE SYSTEM

IMPORTANT All appropriate safety equipment (gloves, tools etc.) must be used during the installation of this product(s). Nitro Dave's LLC accepts NO responsibility for injuries resulting in the installation of any product(s). Nitrous oxide is for off-road use only.



12-10119-WFR WinMax Wiring Harness

WINMAX PIN OUT SHEET



CONTROLLER	
ORANGE	16GA 12V - ARM SWITCH
BLACK	16GA BATTERY GROUND
GREEN/WHITE	18GA TPS INPUT - ECM LOCATION
PURPLE/WHITE	18GA TACH INPUT - ECM LOCATION
GREEN/ORANGE	18GA PIN 85 STAGE 1 RELAY
YELLOW/BLUE	18GA PIN 85 STAGE 2 RELAY
WHITE/BLACK	18GA PIN 30 STAGE 1 IGN RETARD RELAY
RED/BLUE	18GA PIN 30 STAGE2 IGN RETARD RELAY
SWITCH PANEL	
RED/WHITE	16GA 12V KEY SWITCHED
BLACK	16GA BATTERY GROUND
ORANGE	16GA WINMAX,DED F.P.S.S. - ARM SW.
LT.BLUE/WHITE	18GA PIN 86 PURGE RELAY
TAN/PINK	16GA PIN 86 HEATER RELAY W/N.P.S.S.
TAN/ORANGE	18GA PIN 85 OPENER RELAY#10
TAN/GREEN	18GA PIN 85 OPENER RELAY #9
STAGE 1 SOLENOID(S)	
GREEN	10GA PIN 87 STAGE 1 RELAY
BLACK	10GA BATTERY GROUND
STAGE 2 SOLENOID(S)	
YELLOW	10GA PIN 87 STAGE 2 RELAY
BLACK	10GA BATTERY GROUND
ORANGE	16GA FUEL PRESSURE SAFETY SWITCH
ORANGE	16GA FUEL PRESSURE SAFETY SWITCH
PURGE SOLENOID	
BLUE	12GA PIN 87 PURGE RELAY
BLACK	12GA BATTERY GROUND
N.P.S.S. NITROUS PRESSURE SAFETY SWITCH	
TAN/PINK	16GA FROM HEATER SWITCH
TAN/PINK	16GA PIN 86 HEATER RELAY
F.P.S.S. FUEL PRESSURE SAFETY SWITCH	
ORANGE	16GA FROM ARM SWITCH
ORANGE	16GA PIN 86 DEDICATED RELAY
BOTTLE HEATER	
PINK	10GA BTL HEATER- PIN 87 RELAY#6
BLACK	10GA BATTERY GROUND
BOTTLE OPENER	
PURPLE	12GA BTL OPENER - PIN30 RELAY#10
BROWN/WHITE	12GA BTL OPENER - PIN30 RELAY#9
12V SWITCHED POWER	
RED/WHITE	16GA SW PANEL - VEHICLE FUSE PANEL
TRANS BRAKE INPUT	
GREEN	18GA SW PANEL - STAGE INTERRUPT RELAY
DEDICATED FUEL TANK	
PURPLE/ORANGE	12GA TANK - PIN 87 RELAY#5
BLACK	12GA TANK- BATTERY GROUND
ORANGE	16GA F.P.S.S. - ARM SW&PIN86 RELAY#5
ORANGE	16GA F.P.S.S. - STAGE INTERRUPT RELAY#3

RELAY CENTER	
RELAY#1 STAGE 1	
RED	10GA FUSE #1- PIN 30 RELAY
GREEN	10GA STG1 SOL - PIN 87 RELAY
ORANGE	16GA JMPR TO RELAYS 1,2,3,7,8, PIN 85
GREEN/ORANGE	1GA PIN 86 - WINMAX CONTROLLER
RELAY#2 STAGE 2	
RED	10GA FUSE #2 - PIN 30 RELAY
YELLOW	10GA STG 2 SOL - PIN 87 RELAY
ORANGE	16GA JMPR TO RELAYS 1,2,3,7,8, PIN 85
YELLOW/BLUE	18GA PIN 86 - WINMAX CONTROLLER
RELAY#3 STAGE INTERRUPT	
BLACK	16GA BATTERY GROUND JMPR
ORANGE	16GA JMPR TO RELAYS 1,2,3,7,8
ORANGE	16GA F.P.S.S.
GREEN	18GA TRANS BRAKE INPUT
RELAY#4 PURGE	
RED	10GA FUSE#4 - PIN 30 RELAY
BLUE	12GA PIN 87 - PURGE SOL
BLACK	16GA PIN 86 TO BATTERY GROUND
LT.BLUE/WHITE	18GA PIN 85 - SWITCH PANEL
RELAY#5 DEDICATED	
RED	12GA FUSE#5 - PIN 30 RELAY
BLACK	16GA BATTERY GROUND -PIN 86
PURPLE/ORANGE	12GA PIN 87 - DEDICATED TANK
ORANGE	16GA PIN 85 - SWITCH PANEL
RELAY#6 BOTTLE HEATER	
RED	10GA PIN 30 - FUSE #3
PINK	10GA PIN 87 - BOTTLE HEATER
BLACK	16GA PIN 86 - BATTERY GROUND
TAN/PINK	16GA PIN 85 - HEATER SW PANEL
RELAY#7 STAGE 1 TIMING	
BLACK	16GA PIN 86 - JMPR GROUNDS
ORANGE	16GA PIN 85- JMPR REL 1,2,3,7,8
WHITE/BLACK	18GA PIN 30 - WINMAX CONTROLLER
WHITE/BLACK	18GA PIN 87 - TIMING CONTROLLER
RELAY#8 STAGE 2 TIMING	
BLACK	16GA PIN 86- JMPR GROUNDS
ORANGE	16GA PIN 85- JMPR REL 1,2,3,7,8
BLUE/RED	18GA PIN 30 - WINMAX CONTROLLER
BLUE/RED	18GA PIN 87 - TIMING CONTROLLER
RELAY#9 BOTTLE OPENER	
RED	12GA PIN 87 - JMPR REL#10 - FUSE 7
BLACK	16GA PIN 87a,85 JMPR REL#10-GRND
BROWN/WHITE	12GA PIN 30 - BOTTLE OPENER
TAN/GREEN	18GA PIN 86 - OPENER SW PANEL
RELAY#10 BOTTLE OPENER	
RED	10GA PIN 87 - FUSE#7
BLACK	16GA PIN 87a,86 JMPR TO GROUND
PURPLE	12GA PIN 30 - BOTTLE OPENER
TAN/ORANGE	18GA PIN 85 - OPENER SW PANEL

IMPORTANT All appropriate safety equipment (gloves, tools etc.) must be used during the installation of this product(s). Nitro Dave's LLC accepts NO responsibility for injuries resulting in the installation of any product(s). Nitrous oxide is for off-road use only.