

KIT BREAKDOWN		
Part Number	Qty.	Description
05-9755	4	Rear Control Arm Spacers
55-01-9750	2	Front Strut Spacer
55-02-9750	2	Rear Coil Spring Spacers
55-03-9750	2	Front Sway Bar Bracket
MS90841	2	Front Sway Bar Links
77-9750	1	Hardware Bag: Kit

Step	Part Number	Qty. Per Kit	Description	New Attaching Hardware	Qty. Per Bracket	Hardware Bag Number
FRONT						
14	55-01-9750	2	Front Strut Spacer	8mm x 25mm bolt, 1.25 pitch	3	77-9750
				8mm washer	3	
				8mm lock washer	3	
23	55-03-9750	2	Front Sway Bar Bracket	12mm x 40mm bolt, 1.75 pitch	1	77-9750
				12mm washer	1	
				12mm flange nut, 1.75 pitch	1	
24	MS90841	2	Front Sway Bar Links			
REAR						
9	05-9755	4	Rear Control Arm Spacers	14mm x 60mm bolt, 2.0 pitch	1	77-9750
				14mm washer	1	
				14mm lock washer	1	
11	55-02-9750	2	Rear Coil Spring Spacers			